

Precision Universal Testing Machines  
AUTOGRAPH

# AGX<sup>TM</sup>-V2 Series

## Instruction Manual

Read this manual thoroughly before you use the product.  
Keep this manual for future reference.

This page is intentionally left blank.

# Introduction

## Read this Instruction Manual thoroughly before using the product.

Thank you for purchasing this product.

This manual explains about basic use of the product. For details of the use, refer to the separate reference manual. Read this manual and the reference manual carefully for correct use.

The following manuals are included with the product.

Manual Name	Manual No.	Description
AGX-V2 Series Instruction Manual	349-11981	This manual. It explains about basic use.
AGX-V2 Series Reference Manual	349-11986	The manual explains about detailed use and is provided as a PDF file in the DVD-ROM.
Voice Control Device Instruction Manual	349-13006	The manual explains about detailed use of the voice control device.
Operation Controller Instruction Manual	349-11595	The manual explains about detailed use of the operation controller. (optional item)

Keep the manuals for future reference.

### **Important**

- If the user or usage location changes, ensure that the manuals are always kept together with the product.
- If the manual or a product warning label is lost or damaged, immediately contact your Shimadzu representative to request a replacement.
- To ensure safe operation, read all "[Safety Instructions](#)" thoroughly before using the product.
- To ensure safe operation, contact your Shimadzu representative if product installation, adjustment, re-installation (after the product is moved), or repair is required.





### **Notice**

- Information in this manual is subject to change without notice and does not represent a commitment on the part of the vendor.
- Any errors or omissions which may have occurred in this manual despite the utmost care taken in its production will be corrected as soon as possible, although not necessarily immediately after detection.
- All rights are reserved, including those to reproduce this manual or parts thereof in any form without permission in writing from Shimadzu Corporation.
- Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries.  
Third-party trademarks and trade names may be used in this publication to refer to either the entities or their products/services, whether or not they are used with trademark symbol "TM" or "®".







## Indications Used in This Manual

Precaution symbols are indicated using the following conventions:

Indication	Meaning
 <b>DANGER</b>	Indicates an imminently hazardous situation which, if not avoided, will result in serious injury or death.
 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided, could result in serious injury or possibly death.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided, may result in minor to moderate injury or equipment damage.
 <b>NOTE</b>	Emphasizes additional information that is provided to ensure the proper use of this product.

The following symbols are used in this manual:

Indication	Meaning
 Prohibition	Indicates an action that must not be performed.
 Instruction	Indicates an action that must be performed.
 <b>Hint</b>	Indicates information provided to improve product performance.
 <b>Reference</b>	Indicates the location of related reference information.

## Safety Instructions

The material testing machine generates large force to measure mechanical strength of materials and products. Inappropriate handling may cause serious damage to users (injury or death) or property damage.

To ensure safe product operation, read these important safety instructions carefully before use and follow all precaution instructions given in this section.

### ■ Product Applications

#### WARNING



Prohibition

**Do NOT use the product for purposes other than those specified.**

- This product is the material testing machine.
- Using it for an unspecified purpose may result in an accident.
- This product (including accessories) is manufactured for measuring and industrial purposes, and not suitable for household usage.



Instruction

**Safety regulations and standards**

For notifications on installation and safety controls, follow the necessary procedures in compliance with the laws and regulations applicable in the country where the product is used.

### ■ Installation Site

#### WARNING



Prohibition

**Do NOT install the product in a place where flammable or explosive gas or liquid exists.**

This product does not have explosion-proof structure. Therefore, installing it in such an area may result in a fire or explosion.



Instruction

**Install the instrument in a location that satisfies the following conditions.**

Failing to do so may result in electric shock or fire.

- The room temperature is maintained between +5 and +40 °C, with minimal temperature variation during a day.
- Air currents from heating or air conditioning equipment are not directed onto the instrument.
- Ensure that instrument is not exposed to direct sunlight.
- There is no vibration.
- Humidity is maintained within 20 to 80 %.
- There is no condensation.
- The location conforming to the installation environment (IEC)  
Installation category II, Pollution degree: 2, Altitude: Up to 2000 m, Indoor

**⚠ CAUTION**

Prohibition

Do **NOT** install the product in a place where corrosive gas, gas containing organic solvents/halide/siloxane groups, oil mist, or much debris/dust exists.

Otherwise performance may not be maintained or the product life may become shorter than expected.



Prohibition

Do **NOT** use the product in an environment where condensation may be caused on the product.

Otherwise the product may become malfunctioned.



Instruction

Install the product in locations where it can be turned on and off easily.

The product must be turned off immediately in an emergency.

**■ Installation****⚠ WARNING**

Instruction

To ensure safe operation, contact your Shimadzu representative if product installation, adjustment, or re-installation (after the product is moved) is required. And be sure to observe our installation manual to install and adjust the product.

Installing, adjusting, or re-installing the product by yourself may cause an injury or equipment failure, or affect stable operation of the product.



Instruction

Be sure to ground the grounding terminal of the power supply cable.

Failure to do so may result in an electric shock.

- 100 V model Type-D (100  $\Omega$  or less)
- 200 V model Type-D (100  $\Omega$  or less)
- 400 V model Type-C (10  $\Omega$  or less)



Instruction

Use a power supply cable specified by us or supplied with the product.

Failure to do so may result in an electric shock or fire. And a power supply cable specified by us or supplied with the product must not be used with other equipment. The product (including accessories) is for measurement and industrial use and unsuitable for home use.

**! CAUTION**

Instruction

**Be aware of gaps around the instrument during installation.**

If your fingers get caught, it may result in an injury.



Instruction

**When adjusting the angle or direction of the operation controller, be careful not to allow the operation controller to fall off from the stand arm.**

The operation controller will drop and may cause injury or equipment failure.

**NOTE**

- After adjusting the height or angle of the operation controller, be sure to tighten its handle to fix the operation controller.
- Contact your Shimadzu representative for wiring the power supply cable.
- Power supply capacities specified in "[7.1 Basic Specifications](#)" are the figures in the stationary state.
- Use a surge protection breaker in the power supply system against inrush current that runs when the power is turned on.
- A power supply voltage outside the range of the rated value  $\pm 10\%$  may cause malfunction or damage to parts.
- Provide a stabilized power supply if large variation occurs in the power supply voltage.

**■ Operation****! DANGER**

Prohibition

**Do NOT place your hand, head or any other body part in the test space while the crosshead is operating.**

Being caught by the instrument may result in serious injury or death.



Prohibition

**Do NOT open the ball screw protection cover. Do NOT move the crosshead with the ball screw protection cover opened.**

Otherwise a body part may be caught by the rotating ball screw.



Instruction

**Operators must read the instruction manual thoroughly for correct use. And manage so that a person other than those who have been trained about how to operate cannot use the product.**

A dangerous level of force is generated at the moving part according to the capacity of the product. Wrong use may result in serious injury or death.

**! WARNING**

Prohibition

**Never touch a high voltage part of the controller inside the instrument.**

Failure to do so may result in an electric shock.



Prohibition

**Do not place jigs on the rear cover.**

If you put your body into the test space, your body may get caught in the jig and get injured.



Instruction

**If your instrument does not have a protection cover, keep face or other body parts away from a specimen during a test.**

Fragments of a fractured specimen may scatter and damage your eyes and body. Wear protective glasses and install a cover if a fractured specimen may scatter.



Instruction

**Always operate the power breaker from the rear side of the instrument. Never reach through the testing space to operate the power breaker.**

Operating the power breaker when body or extremities are in the testing space may cause injury from crushing.



Instruction

**If the instrument emits abnormal odor or noise, immediately stop using the instrument, press the emergency stop switch, and disconnect the power supply cable.**

Serious failure may occur or injury may occur due to misuse or unexpected operation of this instrument.

**! CAUTION**

Prohibition

**Do not use the crosshead upper and lower limit switches as a condition to stop a test.**

A jig may hit and damage the frame, another jig or the load cell, which may result in injury of an operator.



Instruction

**Keep hands away from the moving part since the crosshead moves rapidly during return or offset based on the registered distance between jigs. Be careful to prevent jigs from interfering with nearby objects.**

A hand of an operator may be caught, resulting in injury, or nearby objects may be damaged. Immediately press the emergency stop button if the instrument movement is abnormal.



Instruction

**Specify the estimated movable range of the crosshead correctly with the crosshead upper and lower limit switches.**

A jig may hit and damage the frame, another jig or the load cell, which may result in injury of an operator.

- Specify the range that can prevent the jig on the crosshead from interfering with the yoke or the jig on the table when the crosshead moves up or down.
- If you have any difficulty in limiting the range, at least specify the range by keeping 20 mm or more clearance between the grips.
- After fixing the crosshead upper and lower limit switches, try to move them up or down to check for slippage.



Instruction

**The crosshead limit switches stop within 5 mm from the set positions. Set the positions of the crosshead limit switches to a position 5 mm away from the position where you desire to stop the crosshead limit switches.**

Otherwise the jigs may interfere with each other.



Instruction

**A test jig heavier than 10 kg should be carried very carefully not to drop. A jig heavier than 20 kg should be carried by a person who has been trained about transportation of heavy goods. Use a crane as necessary.**

Otherwise, an operator may get injured if a jig falls.



Instruction

**If the lock nut is loosened excessively, the grip may fall. Be careful not to lower by 5 mm or more.**

Otherwise, an operator may get injured if a jig falls.



Instruction

**For safety, wear protective gloves, safety shoes, cap or helmet, and protective glasses, when replacing jigs, installing or removing the specimen.**

- There is a risk of the jigs pinching your fingers and causing injury.
- There is a risk of your hand slipping when applying force, causing injury to your fingers.
- There is a risk of an operator being injured if a jig falls.
- There is a risk of your fingers getting injured from contact with the fractured surface of the specimen.



Instruction

**Wear protective gloves when touching a fractured specimen.**

Touching sharp fractured surface of a specimen may result in injury.

## ⚠ CAUTION



Instruction

The crosshead moves rapidly during return or offset based on the registered distance between jigs. Be sure to check the arrow direction displayed on the controller before starting the return movement.


Otherwise an operator may touch the crosshead and get injured.



Instruction

For the standard model, wide model, and separately installed controller model, fix the load cell cable to the cable guides on the rear of the crosshead and the side of the pole.


Check that the cable length is sufficient for reaching within the crosshead travel range. Failing to do so may cause an equipment failure.



Instruction

For the reinforced yoke model, fix the load cell cable at a position away from the crosshead travel range so that the cable does not get caught in the crosshead.

Failing to do so may cause an equipment failure.



- NOTE
- Make sure that the mass of the jig is no more than 20 % of the load cell capacity rating.
  - Continuous operation of this product is limited to less than ten hours. Do not exceed the limitation.
  - There are use restrictions for cycle test.
    - ▶▶ Reference "7.3 Use Restrictions and Installation Environment" P.126
  - Before replacing a load cell, turn off the power or disconnect the CAL connector from the smart controller or operation controller according to the specified procedure.  
Connecting/disconnecting the CAL connector during ECAL or other data communication may corrupt calibration data.
  - Tighten the supplied bolt until the load cell is secured to the crosshead without looseness. Otherwise test force may not be measured correctly.
  - Do not remove or loosen the locating plate for load cell on the top surface of the crosshead. Otherwise, a correct position of the load cell cannot be set.
  - A load cell and CAL connector are calibrated as a set before shipment. Be sure to use a set of a CAL connector and load cell that are included in the same package. Connecting any CAL connector other than the supplied one will cause an abnormal test force preventing the load cell from properly detecting overload.
  - Tests cannot be performed after the load cell is replaced/attached unless E-CAL is executed.
  - Do not perform operation that may apply load to the crosshead while a load cell is not attached or cannot receive transmitted load.  
Doing so may damage the frame or jig.
  - To make the initial setting of distance between jigs, measure accurate values at the time of setting.  
If inaccurate values are input, the jigs may interfere with each other.
  - If the jigs have been changed, be sure to make the initial setting of distance between jigs.  
Otherwise the jigs may interfere with each other.
  - Be careful to prevent water from entering inside of the instrument since the instrument may be damaged.
  - The instrument has a "TouchLoad function" that forces the crosshead to stop when a given level of fluctuations in load applied to the load cell is sensed in the jog operation or during return.  
The function that is enabled by one of the protection circuits may not completely prevent danger due to overshooting in high-speed operation. In addition, it does not stop movement in the unloading direction to ensure safety and operational convenience.  
The function does not guarantee prevention of collision or overloading in the test space.  
Do not use the function for positioning or control.
  - Damages to the load cell due to overshooting may not be completely prevented if collision occurs during high-speed movement in a compression test, etc.
  - To perform E-CAL of test force, apply no load and wait for at least 15 minutes after powering the load cell.



- NOTE**
- Acceptable test force of a load cell is 150 % of the load cell capacity rating, which includes weight of jigs, in tension and compression tests. For load cells with small capacity, be careful about overload on the detector and risk that the load cells fall and fail.
  - Turn off the power before opening the ball screw protection cover. Also, be sure to close the ball screw protection cover before turning on the power.
  - Be careful to prevent water from entering inside of the instrument since the instrument may be damaged.
  - If a computer is connected, an error cannot be cleared from the operating panel. Press the Clear Error button shown on the screen of the computer.
  - If any error code other than those listed "[5.2.2 Alarm Code List](#)" is displayed, hardware failure other than system errors should also be considered. Contact your Shimadzu representative.
  - After initialization, the crosshead position is reset and the test conditions and system settings are all initialized. Be sure to set them again.
  - Initialization does not clear the load cell information stored in the CAL connector.

## ■ Inspection and Maintenance

### WARNING



Instruction

**A person with necessary expertise should perform wiring, maintenance and inspection.**

Otherwise an electric shock, injury, or fire may occur.

## ■ Repair, Disassembly and Modification

### CAUTION



Prohibition

**Do NOT perform unauthorized modification or disassembly.**

Doing so may cause an electric shock, short-circuit, resulting in an accident. Doing so may also cause injury or failure.



Instruction

**Contact your Shimadzu representative for repair.**

Otherwise a fire, electric shock, or injury may result.

## ■ Measures against Earthquake

As a measure against earthquake, fix the instrument on the floor to prevent the instrument from falling down.

Fall-prevention fittings to fix the instrument onto floor are available as optional products. Contact us for purchasing the fittings.

## ■ In an Emergency


Perform the following in case of abnormality that the crosshead does not stop or there is an odor of burning or in case of power failure.

Before starting to use the instrument again, inspect it and if necessary, contact a Shimadzu service personnel.


### To stop the instrument in an emergency (power failure)

- 1 Press the emergency stop switch of the instrument.
- 2 Press the power button of the control box and follow the instructions on the controller screen to turn off the instrument.
- 3 Turn off the power supply breaker (by pressing it downward) on the rear side of the instrument.
- 4 Turn off the primary side power supply breaker (of your facility) to cut power supply.


### AGX-10kNV2D




AGX-20kNV2D / 50kNV2D



AGX-50kNV2 / 100kNV2 / 300kNV2



AGX-600kNV2



## Warning Labels

In order to ensure safety, warning labels are attached in places requiring caution. If a warning label is lost or damaged, obtain a new label through your Shimadzu representative and attach it in the correct position. See "Warning Labels on the Equipment" in this Instruction Manual for details on the positions where the labels are attached

### ■ Front Side






Table-top type



Floor type

No.	Warning Label	Description
①		Pinch point. (Part No.: S037-72999-34) Keep hands clear while the crosshead is moving.

■ Rear Side (standard model, reinforced yoke model, wide test space model)







Table-top type



Floor type


No.	Warning Label	Description
①		Electric shock hazard (Part no.: S037-72999-04) There is a risk of electric shock. Do NOT disassemble the product. Turn off the power before disconnecting a cable.

■ Rear Side (separately installed controller model)



AGX-V/R controller

Floor type

No.	Warning Label	Description
①		Electric shock hazard (Part no.: S037-73999-04) There is a risk of electric shock. Do NOT disassemble the product.


NOTE The appearance of the testing machine varies depending on its type and capacity. The testing machine shown in the figure is AGX-50kNV2S.

## Residual Risk Information

A residual risk indicates a risk that could not be reduced or eliminated in the process of design and manufacture. Check the risk locations in "[Residual Risk Map](#)", and take the relevant protective measures described in "[List of Residual Risks](#)".

### ■ Residual Risk Map

The "Mechanical Location" and "No." indicated below are in accordance with those in "[List of Residual Risks](#)". For details, see "[List of Residual Risks](#)" P.xix.





## ■ List of Residual Risks

The "No." and "Mechanical Location" indicated below are in accordance with those in "Residual Risk Map". Be sure to check the actual "Mechanical Location" referring to "Residual Risk Map" P.xviii.

Furthermore, read through and understand the content in "Reference" to take appropriate protective measures.

### Preparation

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
1	B	<p><b>⚠ WARNING</b></p> <p>Your hand may be caught by the pneumatic flat grips when they catch a specimen.</p>	Use the finger guard supplied with the pneumatic flat grips.	Reference	Instruction Manual for Pneumatic Flat Grips
				Operation Category	Attaching samples
				Required Qualification/ Education	Qualified person received training to use the instrument
2	B	<p><b>⚠ WARNING</b></p> <p>The upper grip is put on the top of the lower grip when the upper grip is attached. The upper grip may fall if it is unstable on the lower grip.</p>	Ensure that the surface where the upper grip is put has no bump and the upper grip can be stable on it.	Reference	AGX-V2 Series Reference Manual
				Operation Category	Attaching test jigs
				Required Qualification/ Education	Qualified person received training to use the instrument
3	B	<p><b>⚠ WARNING</b></p> <p>When the screwed upper compression plate is removed from the load jig, the upper compression plate may suddenly come off from the screw and you may fail to hold the weight of the falling plate, causing your hand to be pinched.</p>	Purchase and use the multi-joint vacuum adapter.	Reference	AGX-V2 Series Reference Manual
				Operation Category	Attaching test jigs
				Required Qualification/ Education	Qualified person received training to use the instrument

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
4	D	<p><b>⚠ CAUTION</b></p> <p>If a bent power cable is used for a long time, the cable covering may break, leading to short-circuit.</p>	Do not bend the power cable and keep any load away from the wired power cable.	Reference	Chapter 2 ( P.13)
				Operation Category	Connecting a power supply
				Required Qualification/ Education	Qualified person received training to use the instrument
5	E	<p><b>⚠ CAUTION</b></p> <p>A person may trip over the load cell cable sagging onto the floor and cut the cable or fall down.</p>	Use the supplied cable clamp to prevent the load cell cable from sagging onto the floor.	Reference	3.2.1 ( P.35)
				Operation Category	Connecting a load cell
				Required Qualification/ Education	Qualified person received training to use the instrument
6	B	<p><b>⚠ CAUTION</b></p> <p>A small load cell may break if large torque is applied while a jig is attached to it.</p>	Carefully read the handling instructions supplied with the load cell to apply appropriate force to fix a jig.	Reference	AGX-V2 Series Reference Manual
				Operation Category	Attaching test jigs
				Required Qualification/ Education	Qualified person received training to use the instrument
7	B	<p><b>⚠ WARNING</b></p> <p>An operator may accidentally drop a test jig when attaching or removing it.</p>	Be extremely careful not to drop a test jig when attaching or removing it. Wear protective gloves when installing and removing the jig.	Reference	AGX-V2 Series Reference Manual
				Operation Category	Attaching samples
				Required Qualification/ Education	Qualified person received training to use the instrument

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
8	B	<p><b>⚠ CAUTION</b></p> <p>Jigs hit each other if the set positions of the crosshead limit switches are inappropriate.</p>	Check the positions of the crosshead limit switches before starting a test.	Reference	<a href="#">3.5.1 ( P.57)</a>
				Operation Category	Setting of the test conditions
				Required Qualification/ Education	Qualified person received training to use the instrument
9	B	<p><b>⚠ WARNING</b></p> <p>Your hand may be caught between the compression plates of the compression cage.</p>	Do not touch the compression cage while the testing machine is operating.	Reference	Instruction Manual for Cage-Type Compression/ Bending Test Devices
				Operation Category	Attaching test jigs
				Required Qualification/ Education	Qualified person received training to use the instrument
10	B	<p><b>⚠ CAUTION</b></p> <p>Jigs hit each other when the crosshead is operated in the high-speed jog mode.</p>	Perform low-speed jog operation if the distance between jigs is short.	Reference	<a href="#">3.4.1 ( P.45)</a>
				Operation Category	Preparing for a test
				Required Qualification/ Education	Qualified person received training to use the instrument

## Test

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
11	A	<p><b>⚠ WARNING</b></p> <p>If a test is performed with the load cell cable passed through the hole in the middle of the crossyoke, your hand may be caught between the crossyoke and load cell when you try to adjust the load cell during the test.</p>	Fix the load cell cable with the cable clamp supplied with the crosshead. For the reinforced yoke model, fix the load cell cable with the cable clamps at the side and upper part of the pole.	Reference	<a href="#">3.2.1 ( P.35)</a>
				Operation Category	During a test
				Required Qualification/ Education	Qualified person received training to use the instrument
12	C	<p><b>⚠ CAUTION</b></p> <p>The emergency stop switch is not easily accessible and cannot be pressed instantly in an emergency.</p>	If the emergency stop switch is not easily accessible, purchase a handy emergency stop switch separately. The reinforced yoke model is provided with the additional emergency stop switch. Install it in a position accessible during testing.	Reference	<a href="#">Chapter 2 ( P.13)</a>
				Operation Category	During a test
				Required Qualification/ Education	Qualified person received training to use the instrument
13	B	<p><b>⚠ CAUTION</b></p> <p>The crosshead moves in the reverse direction due to incorrectly set test conditions.</p>	Check the crosshead movement direction displayed when a test is started.	Reference	<a href="#">3.6.1 ( P.62)</a>
				Operation Category	When starting a test
				Required Qualification/ Education	Qualified person received training to use the instrument
14	B	<p><b>⚠ WARNING</b></p> <p>An operator may be injured if he/she is hit by fragments of a broken specimen.</p>	Use the protection cover. If the protection cover cannot be used for the size of the specimen or test jig, wear protective glasses and take a protective measure before starting a test.	Reference	<a href="#">3.5.2 ( P.60)</a>
				Operation Category	During a test
				Required Qualification/ Education	Qualified person received training to use the instrument

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
15	B	<p><b>⚠ CAUTION</b></p> <p>An operator may cut his/her hand with a sharp edge of a broken specimen.</p>	Wear gloves when removing a broken specimen.	Reference	AGX-V2 Series Reference Manual
				Operation Category	After a test
				Required Qualification/ Education	Qualified person received training to use the instrument
16	B	<p><b>⚠ WARNING</b></p> <p>An operator may be injured when entering the test space while the crosshead is operating.</p>	Use the protection cover. If the protection cover cannot be used for the size of the specimen or test jig, wear protective glasses and keep enough distance from the test space while performing a test.	Reference	3.5.2 ( P.60)
				Operation Category	During a test
				Required Qualification/ Education	Qualified person received training to use the instrument
17	B	<p><b>⚠ WARNING</b></p> <p>The protection cover sensor is removed and a test is performed with the cover opened.</p>	Do not remove the protection cover sensor.	Reference	3.5.2 ( P.60)
				Operation Category	During a test
				Required Qualification/ Education	Qualified person received training to use the instrument
18	B	<p><b>⚠ WARNING</b></p> <p>An operator may be caught by the rotating ball screw when performing a test with the ball screw protection cover opened.</p>	Do not open the ball screw protection cover during a test.	Reference	Chapter 2 ( P.13)
				Operation Category	During test operation
				Required Qualification/ Education	Qualified person received training to use the instrument

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
19	B	<p><b>⚠ CAUTION</b></p> <p>An operator mixes up the up/down buttons when operating the crosshead in the job mode and the crosshead moves in an unintended direction.</p>	Check the jog buttons before operating the crosshead.	Reference	<a href="#">3.4.1 ( P.45)</a>
				Operation Category	During test operation
				Required Qualification/ Education	Qualified person received training to use the instrument
20	B	<p><b>⚠ CAUTION</b></p> <p>After replacement of a test jig, the crosshead is returned to the origin before the replacement, causing a collision of a new test jig.</p>	Be sure to set the crosshead origin again after replacing test jigs.	Reference	<a href="#">3.4.2 ( P.46)</a>
				Operation Category	During test operation
				Required Qualification/ Education	Qualified person received training to use the instrument
21	B	<p><b>⚠ CAUTION</b></p> <p>If the crosshead is moved with the load cell connector disconnected, resulting overload may break a test jig or load cell.</p>	Be sure to perform E-CAL before starting a test.	Reference	<a href="#">3.3.2 ( P.42)</a>
				Operation Category	During test operation
				Required Qualification/ Education	Qualified person received training to use the instrument
22	B	<p><b>⚠ WARNING</b></p> <p>The test is initiated from the computer, and the body and hands are pinched.</p>	When not working alone, communicate well with others.	Reference	<a href="#">3.7.1 ( P.66)</a>
				Operation Category	When starting a test
				Required Qualification/ Education	Qualified person received training to use the instrument

## Maintenance

No.	Mechanical Location	Description	Protective Measure taken by machine user	-	-
23	B	<p><b>⚠ WARNING</b></p> <p>An operator may be caught by the rotating ball screw if he/she operates the crosshead while greasing the ball screw.</p>	Turn off the testing machine before greasing the ball screw.	Reference	4.6.1 ( P.76)
				Operation Category	When greasing the ball screw
				Required Qualification/ Education	Qualified person received training to control the instrument
24	B	<p><b>⚠ CAUTION</b></p> <p>Dropping a weight on foot causes injury.</p>	Wear safety shoes when checking the test force.	Reference	4.4 ( P.73)
				Operation Category	When checking test force
				Required Qualification/ Education	Qualified person received training to control the instrument

## Electromagnetic Compatibility

This is group 1 equipment.

Group 1 equipment: group 1 contains all equipment in the scope of this standard which is not classified as group 2 equipment.

Group 2 equipment: group 2 contains all ISM RF equipment in which radio-frequency energy in the frequency range 9 kHz to 400 GHz is intentionally generated and used or only used locally, in the form of electromagnetic radiation, inductive and/or capacitive coupling, for the treatment of material, for inspection/analysis purposes, or for transfer of electromagnetic energy.

### ■ CISPR11 Emissions (Electromagnetic Interference)

This is a class A product.

Class A equipment is equipment suitable for use in all locations other than those allocated in residential environments and those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

#### CAUTION



Instruction

**When this product causes an electromagnetic disturbance to devices being used near this product, create an appropriate distance between those devices and this product in order to eliminate the disturbance.**

This is a class A product. Class A equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.



## ■ IEC61326-1 Immunity (Electromagnetic Susceptibility)

This product complies with IEC61326-1 immunity, industrial electromagnetic environment for electromagnetic susceptibility (Immunity).

Compliance with these standards does not ensure that the product can operate at a level of electromagnetic interference that is stronger than the level tested. Interference stronger than the values specified above may cause the product to malfunction.

### **When installing or using this product, in an industrial location:**

Locate the product away from any device emitting strong levels of electromagnetic noise. Use a power source that is separated from the power source of any device emitting strong levels of electromagnetic noise.

### **To prevent static electricity:**

Prior to touching the product, the operator should be sure to discharge the static electricity stored in their body by first touching a grounded metallic structure.

Do not touch any terminals or connectors that are not connected to cables while the product is turned ON.

Take the following measures before installing and/or using the instrument in industrial locations:

- Install the instrument away from the device with strong electromagnetic noise.
- Supply power from a different power source.
- Take measures to prevent buildup of static electricity.

## Warranty

Shimadzu provides the following warranty for this product.

### 1. Period:

Please contact your Shimadzu representative for information about the period of this warranty.

### 2. Description:

If a product/part failure occurs for reasons attributable to Shimadzu during the warranty period, Shimadzu will repair or replace the product/part free of charge. However, in the case of products which are usually available on the market only for a short time, such as personal computers and their peripherals/parts, Shimadzu may not be able to provide identical replacement products.

### 3. Limitation of Liability:

- (1) In no event will Shimadzu be liable for any lost revenue, profit or data, or for special, indirect, consequential, incidental or punitive damages, however caused regardless of the theory of liability, arising out of or related to the use of or inability to use the product, even if Shimadzu has been advised of the possibility of such damage.
- (2) In no event will Shimadzu's liability to you, whether in contract, tort (including negligence), or otherwise, exceed the amount you paid for the product.

### 4. Exceptions:

Failures caused by the following are excluded from the warranty, even if they occur during the warranty period.

- (1) Improper product handling
- (2) Repairs or modifications performed by parties other than Shimadzu or Shimadzu designated companies
- (3) Product use in combination with hardware or software other than that designated by Shimadzu
- (4) Computer viruses leading to device failures and damage to data and software, including the product's basic software
- (5) Power failures, including power outages and sudden voltage drops, leading to device failures and damage to data and software, including the product's basic software
- (6) Turning OFF the product without following the proper shutdown procedure leading to device failures and damage to data and software, including the product's basic software
- (7) Reasons unrelated to the product itself
- (8) Product use in harsh environments, such as those subject to high temperatures or humidity levels, corrosive gases, or strong vibrations
- (9) Fires, earthquakes, or any other act of nature, contamination by radioactive or hazardous substances, or any other force majeure event, including wars, riots, and crimes
- (10) Product movement or transportation after installation
- (11) Consumable items

Recording media such as CD-ROMs and DVD-ROMs are considered consumable items.

- \* If there is a document such as a warranty provided with the product, or there is a separate contract agreed upon that includes warranty conditions, the provisions of those documents shall apply.

## After-Sales Service and Availability of Replacement Parts

### ■ After-Sales Service

If any problem occurs with this product, perform an inspection and take appropriate corrective action as described in "5 Troubleshooting".

If the problem persists, or the symptoms are not covered in "5 Troubleshooting", contact your Shimadzu representative.

### ■ Replacement Parts Availability

Replacement parts for this product will be available for a period of seven (7) years after the product is discontinued. Thereafter, such parts may cease to be available.

Note, however, that the availability of parts not manufactured by Shimadzu shall be determined by the relevant manufacturers.

## Maintenance, Inspections, and Adjustment

In order to maintain the instrument's performance and obtain accurate measurement data, daily inspection and periodic inspection/calibration are necessary.

- For daily maintenance, inspection, and replacement parts, see "4 Performance Inspection and Maintenance".
- Periodic inspection/calibration should be requested to your Shimadzu representative.
- Replacement cycles described for periodic replacement parts are a rough estimate. Replacement may be required earlier than the described replacement cycles depending on usage environment and frequency.


## Disposal Precautions

When disposing of the instrument, contact your Shimadzu representative.

If you dispose them yourself, do so in accordance with the processing standards determined by law, separately from general industrial waste and household garbage.

This product contains a battery.

To dispose of it, ask an industrial waste disposer in compliance with the local laws and regulations.



No,	Type	Description
①	CR2032H	Lithium manganese dioxide battery Lithium content: 0.07 g

**NOTE** For California, USA Only  
This product contains a battery that contains perchlorate material. Perchlorate Material - special handling may apply.  
See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate)

# Contents

## Introduction

Indications Used in This Manual .....	iii
Safety Instructions .....	iv
Electromagnetic Compatibility .....	xxvi
Warranty .....	xxviii
After-Sales Service and Availability of Replacement Parts .....	xxix
Maintenance, Inspections, and Adjustment .....	xxix
Disposal Precautions .....	xxx

## 1 Overview

1.1 Testing Frame .....	2
1.2 Component Parts .....	6
1.3 Optional Parts .....	11

## 2 Names and Functions of Parts

2.1 Standard Model, Reinforced Yoke Model, Wide Model .....	13
2.1.1 AGX-V2: Max. 10 kN (Table-Top) Type .....	13
2.1.2 AGX-V2: 20/50 kN (Table-Top) Type .....	15
2.1.3 AGX-V2: 20/50/100/300 kN (Floor) Type .....	17
2.1.4 AGX-V2: 600 kN (Floor) Type .....	19
2.1.5 Control Box .....	21
2.2 Separately Installed Controller Model .....	23
2.2.1 AGX-V2S: Floor Type .....	23
2.2.2 AGX-V/R Controller .....	25
2.3 Operation Unit .....	27
2.3.1 Smart Controller .....	28
2.3.2 Operation Controller .....	30
2.3.3 Voice Control Device .....	32

## 3 Test Procedure

3.1 Test Flow .....	33
3.2 Preparation Before Turning On the Power .....	35
3.2.1 Attaching/Replacing a Load Cell .....	35
3.3 Setting Up the Instrument .....	39

3.3.1	Turning On/Off the Power .....	<b>39</b>
3.3.2	Calibration of a Load Cell .....	<b>42</b>
<b>3.4</b>	<b>Moving the Crosshead .....</b>	<b>45</b>
3.4.1	Moving the Crosshead Up/Down in the Jog Operation .....	<b>45</b>
3.4.2	Performing Crosshead Origin Return with Return Operation .....	<b>46</b>
3.4.3	Switching the Jog Speed .....	<b>48</b>
3.4.4	Registering the Jog Speed, Jog Dial Max. Speed, and Return Speed .....	<b>48</b>
3.4.5	Changing the Distance Between Jigs .....	<b>50</b>
<b>3.5</b>	<b>Configuring/Checking the Safety Devices .....</b>	<b>57</b>
3.5.1	Crosshead Limit Switch .....	<b>57</b>
3.5.2	Protection Cover .....	<b>60</b>
3.5.3	Emergency Stop Switch .....	<b>61</b>
3.5.4	Software Limits .....	<b>61</b>
<b>3.6</b>	<b>Safety Support Functions .....</b>	<b>62</b>
3.6.1	Contact Detect Function .....	<b>62</b>
3.6.2	Overload/Underload Detection Function .....	<b>64</b>
<b>3.7</b>	<b>Starting/Ending a Test .....</b>	<b>65</b>
3.7.1	Starting a Test .....	<b>66</b>
3.7.2	Ending a Test .....	<b>68</b>

**4**

**Performance Inspection  
and Maintenance**

<b>4.1</b>	<b>Periodic Inspection .....</b>	<b>70</b>
<b>4.2</b>	<b>Regular Inspection List .....</b>	<b>70</b>
<b>4.3</b>	<b>Inspection of Safety Devices .....</b>	<b>71</b>
4.3.1	Emergency Stop Switch .....	<b>71</b>
4.3.2	Crosshead Limit Switch .....	<b>71</b>
4.3.3	Protection Cover .....	<b>72</b>
<b>4.4</b>	<b>Checking the Test Force .....</b>	<b>73</b>
<b>4.5</b>	<b>Checking the Stroke Speed .....</b>	<b>75</b>
<b>4.6</b>	<b>Maintenance .....</b>	<b>76</b>
4.6.1	Maintaining the Ball Screws .....	<b>76</b>
4.6.2	Maintaining the Guide Poles .....	<b>77</b>
4.6.3	Replacing the Cooling Fan Filter (Only AGX-V2S Series) .....	<b>78</b>
4.6.4	Cleaning the Operation Unit .....	<b>79</b>

4.6.5	Cleaning the Instrument .....	79
4.7	<b>Usage Time/Counts .....</b>	<b>80</b>
4.7.1	Notification Item .....	82
4.7.2	Checking Usage Time/Counts .....	84

## 5 Troubleshooting

5.1	<b>Introduction .....</b>	<b>86</b>
5.2	<b>Alarm Display .....</b>	<b>86</b>
5.2.1	Alarm Display .....	86
5.2.2	Alarm Code List .....	87
5.3	<b>Other Problems .....</b>	<b>100</b>
5.3.1	Problems About Power Supply .....	100
5.3.2	Problems About Servo Motor .....	100
5.3.3	Problems About Operating Panel .....	101
5.3.4	Problems About Options .....	101
5.4	<b>System Reset .....</b>	<b>102</b>

## 6 Maintenance Parts and Consumables

6.1	<b>Maintenance Parts .....</b>	<b>103</b>
6.2	<b>Consumables .....</b>	<b>103</b>

## 7 References

7.1	<b>Basic Specifications .....</b>	<b>104</b>
7.1.1	Standard Model .....	104
7.1.2	Reinforced Yoke Model .....	107
7.1.3	Wide Model (W1000) .....	109
7.1.4	Separately Installed Controller Model .....	111
7.2	<b>Functional Specifications .....</b>	<b>113</b>
7.3	<b>Use Restrictions and Installation Environment ....</b>	<b>126</b>

<b>Index .....</b>	<b>128</b>
--------------------	------------

This page is intentionally left blank.



The Shimadzu AUTOGRAPH "AGX-V2 Series" are precision universal testing machines achieving a high level of control performance, operability, and safety.

The voice operation function is available to provide correct and safe testing. This function enables you to test start or crosshead return, zero reset of display value through voice. The voice guidance prevents unsafe operation due to carelessness coming from overfamiliarity to realize safe and comfortable operation.

**AGX-V2 series are certified as Shimadzu's Eco-Products Plus.**

The optimized design of the drive system has improved energy density based on the maximum test force × maximum test speed by more than 40 % compared to the previous model (AG-Xplus).



**As an extended series, a wide test space model (hereinafter "wide model"), a separately installed controller model, and a reinforced yoke model have been added to the lineup.**

- Wide model

With this model, the effective width of the test space of the testing machine main unit is expanded to 1,000 mm. In combination with a surface plate, it enables testing of large-sized test specimens that cannot be tested in normal testing machines.

- Separately installed controller model

This is a model where the controller and electrical parts are separated from the testing machine. This model is environmentally resistant, minimizing the effects of breakage shock and conductive dust (carbon fiber, micro wires, etc.) on electrical components.

- Reinforced yoke model

This model can perform tests in a test space above the crosshead. Since tests can be performed above and below the crosshead, it is possible to arrange tensile tests in the upper space and compression or bending tests in the lower space.

Depending on your applications, we provide the Table-top Type and Floor Type testing frames with variations of maximum test force, power supply voltage, and pole extension. A frame model without a protection cover is also available in addition to those in the list below.

## 1.1 Testing Frame

### ■ Table-top Type

Maximum Test Force	Model Type	Power Supply Voltage	Model No.	Pole Extension	P/N
10 kN	Standard model	100 V model	AGX-10kNV2D	Standard	S336-03400-21
			AGX-10kNV2D +250	250 mm Extension	S336-03400-22
			AGX-10kNV2D +500	500 mm Extension	S336-03400-23
		200 V model	AGX-10kNV2D	Standard	S336-03401-21
			AGX-10kNV2D +250	250 mm Extension	S336-03401-22
			AGX-10kNV2D +500	500 mm Extension	S336-03401-23
	Reinforced yoke model	100 V model	AGX-10kNV2D RY	Standard	S336-03400-26
			AGX-10kNV2D +250 RY	250 mm Extension	S336-03400-27
		200 V model	AGX-10kNV2D RY	Standard	S336-03401-26
			AGX-10kNV2D +250 RY	250 mm Extension	S336-03401-27
	Wide model 1000 mm	100 V model	AGX-10kNV2D W10	Standard	S336-03410-21
		200 V model		Standard	S336-03411-21
50 kN	Standard model	200 V model	AGX-50kNV2D	Standard	S336-03402-21
			AGX-50kNV2D +250	250 mm Extension	S336-03402-22
			AGX-50kNV2D +500	500 mm Extension	S336-03402-23
	Reinforced yoke model	200 V model	AGX-50kNV2D RY	Standard	S336-03402-26
			AGX-50kNV2D +250 RY	250 mm Extension	S336-03402-27

## ■ Floor Type

Maximum Test Force	Model Type	Power Supply Voltage	Model No.	Pole Extension	P/N
50 kN	Standard model	200 V model	AGX-50kNV2	Standard	S336-03403-21
			AGX-50kNV2+250	250 mm Extension	S336-03403-22
			AGX-50kNV2+500	500 mm Extension	S336-03403-23
			AGX-50kNV2+750	750 mm Extension	S336-03403-24
		400 V model	AGX-50kNV2	Standard	S336-03404-21
			AGX-50kNV2+250	250 mm Extension	S336-03404-22
			AGX-50kNV2+500	500 mm Extension	S336-03404-23
			AGX-50kNV2+750	750 mm Extension	S336-03404-24
	Separately installed controller model	200 V model	AGX-50kNV2S	Standard	S336-03430-21
			AGX-50kNV2S+250	250 mm Extension	S336-03430-22
			AGX-50kNV2S+500	500 mm Extension	S336-03430-23
			AGX-50kNV2S+750	750 mm Extension	S336-03430-24
	Wide model 1000 mm	200 V model	AGX-20/50kNV2 W10	Standard	S336-03413-21
		400 V model		Standard	S336-03414-21




## 1 Overview






Maximum Test Force	Model Type	Power Supply Voltage	Model No.	Pole Extension	P/N
100 kN	Standard model	200 V model	AGX-100kNV2	Standard	S336-03405-21
			AGX-100kNV2+250	250 mm Extension	S336-03405-22
			AGX-100kNV2+500	500 mm Extension	S336-03405-23
			AGX-100kNV2+750	750 mm Extension	S336-03405-24
		400 V model	AGX-100kNV2	Standard	S336-03406-21
			AGX-100kNV2+250	250 mm Extension	S336-03406-22
			AGX-100kNV2+500	500 mm Extension	S336-03406-23
			AGX-100kNV2+750	750 mm Extension	S336-03406-24
	Separately installed controller model	200 V model	AGX-100kNV2S	Standard	S336-03431-21
			AGX-100kNV2S+250	250 mm Extension	S336-03431-22
			AGX-100kNV2S+500	500 mm Extension	S336-03431-23
			AGX-100kNV2S+750	750 mm Extension	S336-03431-24
	Wide model 1000 mm	200 V model	AGX-100kNV2 W10	Standard	S336-03415-21
		400 V model		Standard	S336-03416-21

Maximum Test Force	Model Type	Power Supply Voltage	Model No.	Pole Extension	P/N
300 kN	Standard model	200 V model	AGX-300kNV2	Standard	S336-03407-21
			AGX-300kNV2+250	250 mm Extension	S336-03407-22
			AGX-300kNV2+500	500 mm Extension	S336-03407-23
			AGX-300kNV2+750	750 mm Extension	S336-03407-24
		400 V model	AGX-300kNV2	Standard	S336-03408-21
			AGX-300kNV2+250	250 mm Extension	S336-03408-22
			AGX-300kNV2+500	500 mm Extension	S336-03408-23
			AGX-300kNV2+750	750 mm Extension	S336-03408-24
	Separately installed controller model	200 V model	AGX-300kNV2S	Standard	S336-03432-21
			AGX-300kNV2S+250	250 mm Extension	S336-03432-22
			AGX-300kNV2S+500	500 mm Extension	S336-03432-23
			AGX-300kNV2S+750	750 mm Extension	S336-03432-24
Wide model 1000 mm	200 V model	AGX-300kNV2 W10	Standard	S336-03417-21	
	400 V model		Standard	S336-03418-21	
600 kN	Standard model	200 V model	AGX-600kNV2	Standard	S336-03409-21
			AGX-600kNV2+250	250 mm Extension	S336-03409-22
			AGX-600kNV2+500	500 mm Extension	S336-03409-23
			AGX-600kNV2+750	750 mm Extension	S336-03409-24
	Separately installed controller model	200 V model	AGX-600kNV2S	Standard	S336-03433-21
			AGX-600kNV2S+250	250 mm Extension	S336-03433-22
			AGX-600kNV2S+500	500 mm Extension	S336-03433-23
			AGX-600kNV2S+750	750 mm Extension	S336-03433-24

## 1.2 Component Parts

■ Standard model, Reinforced yoke model, Wide model AGX-V2

Part Name		Part No.	Qty	Remarks
Testing machine		-	1	-
Smart controller*1	300 kN or less	S336-01055-01	1	-
	For 600 kN	S336-01055-02		
Operation Controller*1		S336-01060	1	-
Voice control device*2	300 kN or less	S336-03372-21	1	Supported language: English
	For 600 kN	S336-03372-22		
Power supply cable*3	AGX-10kNV2D 1φ 200 to 230 V	S336-01192-01	1	<ul style="list-style-type: none"> <li>End shape: M5 round terminal   (L, N, E)                      Length: 3 m                      Cable O.D: φ7.7 mm</li> <li>testing machine side: IEC C14 inlet  </li> </ul>
	AGX-10kNV2D 1φ 100 to 115 V	-	0	Power supply cable is not included. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p><b>NOTE</b> Please prepare a power supply cable that complies with the laws and regulations of each country and region.</p> </div> <ul style="list-style-type: none"> <li>testing machine side: IEC C14 inlet  </li> </ul>

Part Name	Part No.	Qty	Remarks
Power supply cable*3	AGX-20/50kNV2 1 $\phi$ 200 to 230 V	S336-01156-01	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (L, N, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>16.1 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-20/50kNV2 3 $\phi$ 200 to 230 V	S336-01157-01	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>15.3 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-100kNV2 3 $\phi$ 200 to 230 V	S336-01158-01	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>19.0 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-300kNV2 3 $\phi$ 200 to 230 V	S336-01159-01	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>25.5 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-600kNV2 3 $\phi$ 200 to 230 V	S336-01160-01	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>29.0 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
Instruction manual	S349-11981	1	This manual.
Rotation bar	S344-21855	1	Used for replacing jigs.

## 1 Overview

Part Name		Part No.	Qty	Remarks
Hex wrench set	AGX-10kNV2D	S340-48001-09	1	Used for replacing jigs.
	AGX-20/50kNV2D	S340-48001-10		
	AGX-20/50kNV2	S340-48001-10		
	AGX-100/300kNV2	S340-48001-10 S086-03813		
	AGX-600kNV2	S340-48001-10		
Cable clamp		S336-00314	2	For attach to the T-slot of the testing machine pole to secure the load cell cable and the controller cable
Shortcut connector		S336-01180-01	2	For plugging the open operating panel connector.
USB connector cap		S070-09702-02	2	Attach this to an empty USB cable connection port.
External Emergency Stop Switch <sup>*4,*5</sup>		S336-03195-01 <sup>*4</sup>	1	This is an emergency stop switch to be attached to the testing machine pole.
		S336-01511-41 <sup>*5</sup>	1	A tabletop emergency stop switch that can be installed in any position.
Protective glasses		S086-78103-01	1	Wear these when operating the testing machine.
		S086-78105-32		
Protective gloves		S086-78970-11	1	Wear these when replacing jigs, installing or removing the specimen.

\*1 Either one or both items are provided.

\*2 A USB cable is included.



\*3 The item varies depending on the testing machine type. The part No. of the 3 $\phi$  200-230 V power cable varies depending of its length.



\*4 Provided only with the reinforced yoke model.

\*5 Provided only with the wide model including the protection cover.



### ■ Separately installed controller model AGX-V2S

Part Name		Part No.	Qty	Remarks
Testing machine		-	1	AGX-V2S series only
Smart controller* <sup>1</sup>	300 kN or less	S336-01055-01	1	-
	For 600 kN	S336-01055-02		
Operation Controller* <sup>1</sup>		S336-01060	1	-
Voice control device* <sup>2</sup>	300 kN or less	S336-03372-21	1	Supported language: English
	For 600 kN	S336-03372-22		
AGX-V/R controller* <sup>3</sup>	AGX-V/R 50kN 3 $\phi$ 200 to 230 V	S336-03186-42	1	Drive motor: 2.0 kW
	AGX-V/R 100kN 3 $\phi$ 200 to 230 V	S336-03186-43		Drive motor: 3.5 kW
	AGX-V/R 300kN 3 $\phi$ 200 to 230 V	S336-03186-44		Drive motor: 5.5 kW
	AGX-V/R 600kN 3 $\phi$ 200 to 230 V	S336-03186-45		Drive motor: 7.5 kW
Power supply cable* <sup>4</sup>	AGX-V/R 50kN 3 $\phi$ 200 to 230 V	S336-01157-11	1	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E) Length: 5 m Cable O.D: <math>\phi</math>15.3 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-V/R 100kN 3 $\phi$ 200 to 230 V	S336-01158-11		<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E) Length: 5 m Cable O.D: <math>\phi</math>19.0 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>

Part Name		Part No.	Qty	Remarks
Power supply cable*4	AGX-V/R 300kN 3 $\phi$ 200 to 230 V	S336-01159-11	1	<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>25.5 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
	AGX-V/R 600kN 3 $\phi$ 200 to 230 V	S336-01160-01		<ul style="list-style-type: none"> <li>End shape: M5 round terminal  (R, S, T, E)</li> <li>Length: 5 m Cable O.D: <math>\phi</math>29.0 mm</li> <li>testing machine side: Directly fixed cable</li> </ul>
Instruction manual		S349-11981	1	This manual.
Rotation bar		S344-21855	1	Used for replacing jigs.
Hex wrench set	AGX-20/50kNV2S	S340-48001-10	1	Used for replacing jigs.
	AGX-100kNV2S/ 300kNV2S	S340-48001-10 S086-03813	1	Used for replacing jigs.
	AGX-600kNV2S	S340-48001-10	1	Used for replacing jigs.
USB extension cable		S088-50962-07	1	Used for extending the USB cable provided with the voice control device.
Cable clamp		S336-00314	2	For attach to the T-slot of the testing machine pole to secure the load cell cable and the controller cable
Shortcut connector		S336-01180-01	2	Attach this to an empty operation unit connector.
USB connector cap		S070-09702-02	2	Attach this to an empty USB cable connection port.
Protective glasses		S086-78103-01	1	Wear these when operating the testing machine.
		S086-78105-32		
Protective gloves		S086-78970-11	1	Wear these when replacing jigs, installing or removing the specimen.

\*1 Either one or both items are provided.

\*2 A USB cable is included.

\*3 The item varies depending on the testing machine type.

\*4 The item varies depending on the testing machine type. The part No. of the 3 $\phi$  200-230 V power cable varies depending of its length.

## 1.3 Optional Parts

1

### ■ Internal Units

Part Name		Part No.	Qty	Remarks
Sensor Amplifier		S336-01076-01	1	Connect the load cell or displacement gauge via the CAL connector.
CAL Connector	For load cells	S336-01064-01	1	Supports load cells
	For SG displacement gauge	S336-01064-11	1	Supports SG extensometers and SG width gauges.
	For LVDT displacement gauge	S336-01064-21	1	Supports LVDT extensometers and LVDT width gauges.
Analog Input Amplifier		S336-01076-07	1	<ul style="list-style-type: none"> <li>• 4 channels</li> <li>• Analog voltage input</li> </ul>
Analog Output Amplifier		S336-01076-04	1	<ul style="list-style-type: none"> <li>• 4 channels</li> <li>• Analog voltage output</li> </ul>
Strain Amplifier		S336-01076-06	1	<ul style="list-style-type: none"> <li>• 2 channels</li> <li>• Strain gauge bridge</li> </ul>
Counter Unit		S336-01076-05	1	<ul style="list-style-type: none"> <li>• 4 channels</li> <li>• A/B 2-phase pulse, Up/Down pulse</li> </ul>
Isolated PIO Unit		S336-01076-02	1	<ul style="list-style-type: none"> <li>• 16-bit input, 16-bit output</li> <li>• 12 to 24 V AC/DC</li> </ul>
Non-Isolated PIO Unit		S336-01076-03	1	<ul style="list-style-type: none"> <li>• 16-bit input, 16-bit output</li> <li>• 5 V TTL / Open collector</li> </ul>
Analog Recorder Unit		S336-01076-08	1	Connect the AR series analog recorder.
AEH Communication Unit		S336-01076-09	1	Connect the AEH Series automatic extensometer.

▶▶ **Reference** For the maintenance parts and consumables, see "[6 Maintenance Parts and Consumables](#)" P.103.

## ■ AGX-V/R controller unit

Part Name	Part No.	Qty	Remarks
Fall prevention anchor*1	S339-85487-01	1	Hole-in anchor • O.D.: 6 mm • Compatible drill dia.: 6.4 mm
External emergency stop switch	S336-03195-01	1	For adding an emergency stop switch.


\*1 Four pieces of this item are required to fix the controller.

# 2 Names and Functions of Parts

## 2.1 Standard Model, Reinforced Yoke Model, Wide Model


### 2.1.1 AGX-V2: Max. 10 kN (Table-Top) Type

#### ■ Front Side




\* These parts are provided on the right and left sides.

#### ■ Rear Side




## 2 Names and Functions of Parts

No.	Name	Description
①	Crosshead Upper Limit	Set the upper limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
②	Pole*	A structural part for housing a ball screw.
③	Ball Screw Protection Cover*	A cover for protecting the ball screw and preventing a body part from contacting the ball screw.
④	Crosshead	A drive part moving up and down to apply test force to a specimen.
⑤	Ball Screw (installed inside the pole)*	A drive part for transmitting driving force from the motor to the crosshead.
⑥	Crosshead Lower Limit	Set the lower limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
⑦	Table	A structural part for receiving test force given by the crosshead.
⑧	 Emergency Stop Switch*	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the switch in the arrow direction shown on it cancels emergency stop.
⑨	Front Cover	A cover of the drive part.
⑩	Crossyoke	A structural part for connecting poles.
⑪	Load Cell	A load cell is a sensor for measuring test force.
⑫	Protection Cover (for the model with the cover only)	A cover for preventing specimen fragments from scattering when a specimen is broken during a test.
⑬	Smart Controller	A controller for controlling the instrument.
⑭	Operation Controller	A controller for controlling the instrument.
⑮	Voice Control Device	A device to assist test machine operation with voice.
⑯	Control Box	A part for controlling the instrument and performing sensor measurement.
⑰	Power Supply Connector	Used to connect a single phase 100-115 V or 200-230 V source according to the power supply of the instrument.
⑱	Power Supply Breaker	A power supply breaker of the instrument. An earth leakage breaker is provided.
⑲	Cooling Fan	A fan for cooling the drive part.
⑳	Rear Cover	A cover of the drive part.

\* : These parts are provided on the right and left sides.


## 2.1.2 AGX-V2: 20/50 kN (Table-Top) Type

### ■ Front Side




\* These parts are provided on the right and left sides.

### ■ Rear Side



## 2 Names and Functions of Parts


No.	Name	Description
①	Crosshead Upper Limit	Set the upper limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
②	Pole*	A structural part for housing a ball screw.
③	Ball Screw Protection Cover*	A cover for protecting the ball screw and preventing a body part from contacting the ball screw.
④	Crosshead	A drive part moving up and down to apply test force to a specimen.
⑤	Ball Screw (installed inside the pole)*	A drive part for transmitting driving force from the motor to the crosshead.
⑥	Crosshead Lower Limit	Set the lower limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
⑦	Table	A structural part for receiving test force given by the crosshead.
⑧	 Emergency Stop Switch*	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the switch in the arrow direction shown on it cancels emergency stop.
⑨	Front Cover	A cover of the drive part.
⑩	Crossyoke	A structural part for connecting poles.
⑪	Load Cell	A load cell is a sensor for measuring test force.
⑫	Protection Cover (for the model with the cover only)	A cover for preventing specimen fragments from scattering when a specimen is broken during a test.
⑬	Smart Controller	A controller for controlling the instrument.
⑭	Operation Controller	A controller for controlling the instrument.
⑮	Voice Control Device	A device to assist test machine operation with voice.
⑯	Control Box	A part for controlling the instrument and performing sensor measurement.
⑰	Power Supply Cable	Used to connect a single phase 200-230 V source.
⑱	Power Supply Breaker	A power supply breaker of the instrument. An earth leakage breaker is provided.
⑲	Rear Cover	A cover of the drive part.
⑳	Cooling Fan	A fan for cooling the drive part.

\* : These parts are provided on the right and left sides.




2.1.3 AGX-V2: 20/50/100/300 kN (Floor) Type

■ Front Side




\* These parts are provided on the right and left sides.

■ Rear Side




## 2 Names and Functions of Parts

No.	Name	Description
①	Crosshead Upper Limit	Set the upper limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
②	Pole*	A structural part for housing a ball screw.
③	Ball Screw Protection Cover*	A cover for protecting the ball screw and preventing a body part from contacting the ball screw.
④	Crosshead	A drive part moving up and down to apply test force to a specimen.
⑤	Ball Screw (installed inside the pole)*	A drive part for transmitting driving force from the motor to the crosshead.
⑥	Crosshead Lower Limit	Set the lower limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
⑦	 Emergency Stop Switch*	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the switch in the arrow direction shown on it cancels emergency stop.
⑧	Table	A structural part for receiving test force given by the crosshead.
⑨	Front Cover	A cover of the drive part.
⑩	Crossyoke	A structural part for connecting poles.
⑪	Load Cell	A load cell is a sensor for measuring test force.
⑫	Protection Cover (for the model with the cover only)	A cover for preventing specimen fragments from scattering when a specimen is broken during a test.
⑬	Smart Controller	A controller for controlling the instrument.
⑭	Operation Controller	A controller for controlling the instrument.
⑮	Voice Control Device	A device to assist test machine operation with voice.
⑯	Control Box	A part for controlling the instrument and performing sensor measurement.
⑰	Cooling Fan (on the side of the rear cover)	A fan for cooling the drive part.
⑱	Rear Cover	A cover of the drive part.
⑲	Power Supply Breaker	A power supply breaker of the instrument. An earth leakage breaker is provided.
⑳	Power Supply Cable	Used to connect a three-phase 200-230 V or 380-440 V source according to the power supply of the instrument.

\* : These parts are provided on the right and left sides.


## 2.1.4 AGX-V2: 600 kN (Floor) Type

### ■ Front Side




\* These parts are provided on the right and left sides.

### ■ Rear Side




## 2 Names and Functions of Parts

No.	Name	Description
①	Crosshead Upper Limit	Set the upper limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
②	Pole*	A structural part for housing a ball screw.
③	Ball Screw Protection Cover*	A cover for protecting the ball screw and preventing a body part from contacting the ball screw.
④	Ball Screw (installed inside the pole)*	A drive part for transmitting driving force from the motor to the crosshead.
⑤	Crosshead	A drive part moving up and down to apply test force to a specimen.
⑥	Crosshead Lower Limit	Set the lower limit of the crosshead movement range. The crosshead stops when it reaches the set limit position. Be sure to set it before starting a test.
⑦	 Emergency Stop Switch*	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the switch in the arrow direction shown on it cancels emergency stop.
⑧	Table	A structural part for receiving test force given by the crosshead.
⑨	Front Cover	A cover of the drive part.
⑩	Crossyoke	A structural part for connecting poles.
⑪	Load Cell	A load cell is a sensor for measuring test force.
⑫	Protection Cover (for the model with the cover only)	A cover for preventing specimen fragments from scattering when a specimen is broken during a test.
⑬	Smart Controller	A controller for controlling the instrument.
⑭	Operation Controller	A controller for controlling the instrument.
⑮	Voice Control Device	A device to assist test machine operation with voice.
⑯	Control Box	A part for controlling the instrument and performing sensor measurement.
⑰	Cooling Fan (on the side of the rear cover)	A fan for cooling the drive part.
⑱	Rear Cover	A cover of the drive part.
⑲	Power Supply Breaker	A power supply breaker of the instrument. An earth leakage breaker is provided.
⑳	Power Supply Cable	Used to connect a three-phase 200-230 V source.


\* : These parts are provided on the right and left sides.

## 2.1.5 Control Box



Front Side



Rear Side




## 2 Names and Functions of Parts

No.	Name	Description
①	Sensor Amplifier (for load cell) TD1	An amplifier for measuring test force that receives signal input from the load cell.
②	Extension Slot TD2 to TD6	Extension slots for connecting amplifiers for various measuring instruments such as an external extensometer and analog input.
③	Bar Indicator	The bar indicator lights when the power button ⑤ is set to ON. It shows the instrument status with colors. <ul style="list-style-type: none"> <li>• Crosshead is not operating: White</li> <li>• Crosshead is operating: Orange</li> <li>• Test is in progress: Blue</li> <li>• Alarm has occurred: Red</li> </ul>
④	USB Connector	An option connector for connecting a USB device. Do not connect any device other than those undergoing our verification for connection.
⑤	 Power Button	A button for turning on or off the instrument. The bar indicator ③ lights when the power is on.
⑥	Error Indicator	The error indicator lights when an internal error has occurred. If it still lights after the instrument is turned off and on, contact your Shimadzu representative.
⑦	 Standby Button	A button for turning on or off the power to the servo motor.
⑧	Analog Output Connector	A connector for outputting the data (test force, stroke, extension, etc.) measured with the instrument as analog signals to an external device. For the output level, either of $\pm 5$ V or $\pm 10$ V can be selected.
⑨	Operating Panel Connector	Connectors for the smart controller and operation controller.
⑩	Synchronization Connector	A connector for inputting or outputting synchronization signals from or to more than one control boxes.
⑪	Ethernet Connector	An Ethernet connector for connecting a computer to the instrument.
⑫	Interlock Connector	A connector for inputting interlock signals of the protection cover.
⑬	PIO Connector	A connector for I/O signals of an optional device.

## 2.2 Separately Installed Controller Model


### 2.2.1 AGX-V2S: Floor Type



**NOTE**

- The appearance of the Testing Machine varies depending on its type and capacity. The Testing Machine shown in the figure is AGX-50kNV2S.
- The parts with "\*" are provided on the right and left sides.
- The protection cover 12 is equipped on the model with the cover only.

## 2 Names and Functions of Parts


No.	Name	Description
①	Crosshead Upper Limit	Set the upper limit of the crosshead movement range. The servo motor stops when the crosshead pushes up the crosshead limit. Be sure to set the limit before starting a test.
②	Pole*	A structural part for housing a ball screw.
③	Ball Screw Protection Cover*	A cover for protecting the ball screw and preventing a body part from contacting the ball screw.
④	Ball Screw (installed inside the pole)*	Transmits the driving force from the servo motor to the crosshead.
⑤	Crosshead	A drive part moving up and down to apply test force to a specimen.
⑥	Crosshead Lower Limit	Set the lower limit of the crosshead movement range. The servo motor stops when the crosshead pushes down the crosshead limit. Be sure to set the limit before starting a test.
⑦	 Emergency Stop Switch*	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the control part in the direction of the arrow or pulling it cancels the emergency stop.
⑧	Table	A structural part for receiving test force given by the crosshead.
⑨	Front Cover	A cover of the drive part.
⑩	Crossyoke	A structural part for connecting poles.
⑪	Load Cell	A load cell is a sensor for measuring test force.
⑫	Protection Cover (for the model with the cover only)	A cover for preventing specimen fragments from scattering when a specimen is broken during a test.
⑬	Smart Controller	A controller for controlling the instrument.
⑭	Operation Controller	A controller for controlling the instrument.
⑮	Voice Control Device	A device to assist test machine operation with voice.
⑰	Cooling Fan (on the side of the rear cover)	A fan for cooling the drive part.
⑱	Rear Cover	A cover of the drive part.
⑲	Power Control Connection Port	A connection port that connects a AGX-V/R controller and the power and control cables.

\* :These parts are provided on the right and left sides.





## 2.2.2 AGX-V/R Controller


### External Appearance



**NOTE** The appearance of the AGX-V/R controller varies depending on its capacity. The AGX-V/R controller shown in the figure is AGX-V/R 50kN.

No.	Name	Description
①	Bar Indicator	Indicates the controller status with colors. <ul style="list-style-type: none"> <li>• White: Crosshead is not operating.</li> <li>• Orange: Crosshead is operating.</li> <li>• Blue: Test is in progress.</li> <li>• Red: Alarm has occurred.</li> </ul>
②	 Power Button	Turns on the controller power. Pressing the button again starts turning the power off.
③	Error Indicator	Lights up when the controller has an error.
④	 Standby Button	Supplies the power to the servo motor. Pressing the button again starts shutting the power off.
⑤	Power Supply Breaker	Controls the main power of the controller. It has the overcurrent shutoff function and leakage current shutoff function.
⑥	Cooling Fan	A fan for cooling the inside of the controller.
⑦	Filter	A dust filter. Replace it every 6 months.

■ Connector Panel



**NOTE** The parts with "\*" are provided on the front and rear sides.


No.	Name	Description
①	Sensor Amplifier	Connects the load cell.
②*	Extension Slot*	Add optional units on these slots.
③	USB Connector	Connects USB devices.
④	Synchronization Connector	Used for synchronizing multiple controllers.
⑤	Interlock Connector	Connects the limit switch for the protection cover.
⑥	Analog Output Connector	Used for outputting measured values as analog voltage.
⑦	Operating Panel Connector	Connects the operation controller and smart controller.
⑧	Ethernet Connector	Connects a computer.
⑨	PIO Connector	Connects an optional device.

\* These parts are provided on the front and rear sides.

## 2.3 Operation Unit


The operation controller and smart controller can be connected to the control box and AGX-V/R controller.

Function/Performance	Operation Controller	Smart Controller
Operation of Testing Machine	✓	✓
Test condition creation	✓	×
Result display	✓	✓
Hard keys	Start, Return, Stop, Manual ON/OFF, Jog up, Jog down	Manual ON/OFF, Jog up, Jog down
Screen size	8.4 inches	5.0 inches
Installation	Fixed to the Testing Machine	Hooked to the Testing Machine/Hand-held operation


 **Hint** Both the operation controller and smart controller can be connected simultaneously.


## 2.3.1 Smart Controller

### ■ External Appearance



### ■ Screen




No.	Name	Description
①	Touch Panel	Used to display measured values such as test force and stroke, operate the tests, and configure the instrument.
②	Manual Button	Switches between the manual mode for jog operation and the stop mode.
③	Jog Up Button	Raises the crosshead when the manual mode is selected. The crosshead moves up while the button is held down.
④	Jog Down Button	Lowens the crosshead when the manual mode is selected. The crosshead moves down while the button is held down.
⑤	Upper LED Indicator	Lights when the crosshead can be raised or during its motion upward.
⑥	Jog Dial	A dial to raise the crosshead when the manual mode is selected. Turn it clockwise to move the crosshead up, and counterclockwise to move it down.
⑦	Lower LED Indicator	Lights when the crosshead can be lowered or during its motion downward.
⑧	Inter-jig distance	Used to move the crosshead to an appropriate start position according to a registered distance between jigs.
⑨	Specimen protection	Used to automatically adjust the crosshead position to set the force acting on a specimen before starting a test to the setting value.
⑩	Set	Used to change settings.
⑪	Zero Reset	Clears the current measured value to zero. Holding this down displays the submenu.
⑫	Return Home	Used to move the crosshead to the origin (where the position is 0).
⑬	Start Test	Used to start a test. During the test, the button indication changes to  ([Stop Test]).

▶▶ Reference "Precision Universal Testing Machines AUTOGRAPH AGX-V2 Series Reference Manual" (Document No.: 349-08953)


## 2.3.2 Operation Controller

### External Appearance



### Screen





No.	Name	Description
①	Touch Panel	Used to display measured values such as test force and stroke, operate the tests, and configure the instrument.
②	Return Button	Used to move the crosshead to the origin (where the position is 0).
③	Start Button	Used to start a test.
④	 Emergency Stop Switch	A switch for forcibly stopping the crosshead. Pressing the switch cuts power to the servo motor. Turning the control part in the direction of the arrow or pulling it cancels the emergency stop.
⑤	Stop Button	Used to stop a test.
⑥	Manual Button	Switches between the manual mode for jog operation and the stop mode.
⑦	Jog Up Button	Raises the crosshead when the manual mode is selected. The crosshead moves up while the button is held down.
⑧	Upper LED Indicator	Lights when the crosshead can be raised or during its motion upward.
⑨	Jog Dial	A dial to raise the crosshead when the manual mode is selected. Turn it clockwise to move the crosshead up, and counterclockwise to move it down.
⑩	Lower LED Indicator	Lights when the crosshead can be lowered or during its motion downward.
⑪	Jog Down Button	Lowers the crosshead when the manual mode is selected. The crosshead moves down while the button is held down.
⑫	Zero Reset	Clears the current measured value to zero. Holding this down displays the submenu.
⑬	Specimen protection	Used to automatically adjust the crosshead position to set the force acting on a specimen before starting a test to the setting value.
⑭	Inter-jig distance	Used to move the crosshead to an appropriate start position according to a registered distance between jigs.
⑮	Analog out	Used to configure the analog voltage output port.
⑯	Maintenance	Used to check the maintenance information.
⑰	Method	Used to create and edit test conditions.
⑱	File	Used to retrieve and save test conditions.
⑲	Calibration	Used to perform electronic calibration (E-CAL).
⑳	Settings	Used to change settings.

▶▶ Reference "Operation Controller Instruction Manual" (Document No.: 349-11595)

### 2.3.3 Voice Control Device

#### ■ External Appearance



No.	Name	Description
①	Main unit	The main unit of the voice control device.
②	LED indicator	The lighting pattern indicates the operating status of the voice control device.
③	Microphones	Microphones at two places pick up voice sound.
④	USB Cable	Used to connect to the USB connector of the control box or the AGX-V/R controller.
⑤	Stand	A stand for using the device when it is detached from the main unit.
⑥	Fixing plate	A fixing part to be attached to the testing machine.
⑦	Magnet	Used for fixing the device to the testing machine.

▶▶ Reference For details on the voice control device, refer to the "Voice Control Device Instruction Manual" (Document No.: 349-13006)



# 3 Test Procedure

## 3.1 Test Flow

### 1 Preparation before turning on the power

"3.2.1 Attaching/Replacing a Load Cell"



### 2 "3.3 Setting Up the Instrument"

"Turning On the Power"



Turning on the standby button



"3.3.2 Calibration of a Load Cell"

\* Necessary only after turning on the power for the first time



} Warming up  
for 15  
minutes

### 3 Daily inspection

"3.5 Configuring/Checking the Safety Devices"

"3.5.1 Crosshead Limit Switch"

"3.5.2 Protection Cover"

"3.5.3 Emergency Stop Switch"

"3.5.4 Software Limits"



"4.4 Checking the Test Force", "4.5 Checking the Stroke Speed"

\* Recommended after turning on the power for the first time



### 4 Preparation before test

**A** Attaching test jigs

- Moving up/down the crosshead

"3.4.1 Moving the Crosshead Up/Down in the Jog Operation"

- Attaching UJ/LJ (Refer to the reference manual)
- Attaching jigs (Refer to the reference manual)



- Starting a computer
- Starting TRAPEZIUMX-V  
(Refer to the "TRAPEZIUMX-V User Guide")



Go to "Test"

# 5 Test

**B** Creating, saving, and retrieving a test method  
(Refer to the "TRAPEZIUMX-V User Guide")



Configuring the safety devices

- "3.5.1 Crosshead Limit Switch"
- "3.5.4 Software Limits"  
(Refer to the "TRAPEZIUMX-V User Guide")



**C** Attaching a specimen  
(Refer to the reference manual)



"3.7 Starting/Ending a Test"



Removing a specimen



Moving the crosshead to the test start position



Perform the next test

▼ NO

- Exiting TRAPEZIUMX-V  
(Refer to the "TRAPEZIUMX-V User Guide")
- "Turning Off the Power"

▷ YES

Using the same method to perform the next test

▼ NO

▷ YES

Returning to **C** "Attaching a specimen"

▷ YES

Using the same jigs to perform the next test

▼ NO

Returning to **B** "Creating, saving and retrieving a test method"

Returning to **A** "Attaching test jigs"

## 3.2 Preparation Before Turning On the Power

### 3.2.1 Attaching/Replacing a Load Cell

Attach/replace a load cell according to the following procedure.


- ▶▶ **Reference** Precision Universal Testing Machines AUTOGRAPH AGX-V2 Series Reference Manual "3.1 Preparation with the testing machine"

#### 1 Turn off the instrument.

▣ **NOTE** Before replacing a load cell, turn off the power or disconnect the CAL connector from the smart controller according to the specified procedure. Connecting/disconnecting the CAL connector during E-CAL or other data communication may corrupt calibration data.

#### 2 Remove the test jig from the load cell.

#### 3 Loosen the two fixing screws ① of the CAL connector on the right side of the instrument and remove them.



#### 4 Remove the load cell from the crosshead. For the reinforced yoke model, remove the load cell from the yoke.

- For 10 kN or smaller load cells, loosen the fixing bolt of the load cell with a rotation bar and while holding the load cell with one hand, turn the fixing bolt with another hand to remove it.
- For 20 kN or larger load cells, use a hex wrench to loosen the bolt and remove it from the crosshead.


5

Attach the replacement load cell to the crosshead, so that the text on the nameplate of the load cell is shown with the right side up. For the reinforced yoke model, attach the load cell to the yoke.

- NOTE**
- Tighten the supplied bolt until the load cell is secured to the crosshead without looseness. Otherwise test force may not be measured correctly.
  - Do not remove or loosen the locating plate for load cell on the top surface of the crosshead. Otherwise, a correct position of the load cell cannot be set.


6

Connect the load cell side end (1) of the load cell cable to the connector (2) of the load cell securely.



20 kN or larger load cells

- HINT** This connection is not necessary for 10 kN or smaller load cells since they have an integrated load cell cable.




10 kN or smaller load cells

- NOTE**
- A load cell and CAL connector are calibrated as a set before shipment. Be sure to use a set of a CAL connector and load cell that are included in the same package. Connecting any CAL connector other than the supplied one will cause an abnormal test force preventing the load cell from properly detecting overload.
  - Tests cannot be performed after the load cell is replaced/attached unless E-CAL is executed.
    - ▶ Reference ["3.3.2 Calibration of a Load Cell" P.42](#)
  - Do not perform operation that may apply load to the crosshead while a load cell is not attached or the attached load cell cannot receive transmitted load. Doing so may damage the frame or jig.

**7**


Secure the load cell cable to the cable guide ① on the left of the rear side of the crosshead and on the pole side.



Standard model (rear)

**NOTE** When securing the load cell cable to the cable guide, keep enough length of the load cell cable to allow the crosshead to move through the movement range.

For the reinforced yoke model, secure the cable to the cable guide on the pole side.






For the reinforced yoke model (front)

**3**

8

Connect the CAL connector to the sensor amplifier (for load cell) ① and fix it with the connector fixing screws.



 **Hint** The sensor amplifier connector port may be located on the rear side of the control box. Contact your Shimadzu representative.


## 3.3 Setting Up the Instrument


### 3.3.1 Turning On/Off the Power

#### ■ Turning On the Power

**1**

Turn on the power supply breaker on the rear side of the instrument or AGX-V/R controller.



 **Hint** If the load cell and sensor amplifier are already warmed up sufficiently, the warming up can be skipped by pressing the [Cancel] button.


**3**

2

Press  (power button) on the front side of the control box.



The bar indicator on the front side of the control box lights when the power is turned on.


After the power is turned on, the startup screen is displayed on the smart controller and the startup sound is played.



The display changes to the main screen in several tens of seconds.

Warming up continues for 15 minutes after the power is turned on.



 **Hint** If the load cell and sensor amplifier are already warmed up sufficiently, the warming up can be skipped by pressing the [Cancel] button.



**3**

Press  (standby button) on the front side of the control box or AGX-V/R controller.

- NOTE**
- The standby button cannot be active when the emergency stop switch or either of the crosshead limit switches is active.
  - If the emergency stop switch is still held down, turn its control part in the arrow direction to deactivate the switch.

### ■ Turning Off the Power

**1**

Press  (power button) on the front side of the control box or AGX-V/R controller.

A message confirming whether to turn off the power is displayed on the LCD touch panel of the smart controller.

**2**

Select "Yes".

The power turns off.

**3**

If you do not use the instrument for some time, turn off the power supply breaker on the rear side of the instrument or AGX-V/R controller.


**3**

### 3.3.2 Calibration of a Load Cell

- 1 From the LCD touch panel of the smart controller or operation controller execute E-CAL (electronic calibration).

#### When starting up


- 1 Follow the message displayed after warming up ends and press [Execute E-CAL] to execute E-CAL.




#### After starting up

##### ■ Smart Controller

- 1 Press [Set].




- 2 Press [Setting 1] - [Execute E-CAL].





3

## ■ Operation Controller

- 1 Press [Calibration].
- 2 Press [Execute E-CAL].



3 Press [OK] to execute E-CAL.



- NOTE**
- To perform E-CAL of test force, apply no load and wait at least 15 minutes after powering the load cell.
  - E-CAL takes approximately 30 seconds to be completed.
  - Perform no operation until E-CAL is completed.
  - Tests cannot be performed after the load cell is replaced/attached unless E-CAL is executed.
  - The sensitivity of the sensor amplifier changes depending on the ambient temperature. When the ambient temperature changes by  $\pm 10$  °C or more, execute E-CAL again.

**Hint** You can also execute E-CAL from the computer software.

- Reference**
- "3.3.2 Calibration of a Load Cell" P.42
  - "Shimadzu Autograph Software TRAPEZIUM X-V User Guide" (Document No.: 349-08931)

## 3.4 Moving the Crosshead

### ! DANGER



Instruction

Keep hand, head, or any other body part away from the test space while the crosshead is operating.

Being caught by the instrument may result in serious injury or death.



Prohibition

Do NOT open the ball screw protection cover. Do NOT move the crosshead with the ball screw protection cover opened.

Otherwise a body part may be caught by the rotating ball screw.


3

### 3.4.1 Moving the Crosshead Up/Down in the Jog Operation

In the jog operation, you can move the crosshead up/down manually.

1

Press the manual button **3** on the operation controller or the smart controller.



The instrument is set to the manual mode (ready for jog operation), and the upper LED indicator **1** and the lower LED indicator **2** light up.

**Hint** In the AGX-V2S series, you can retract the crosshead with jog operation when it reaches the crosshead limit. In this case, either the upper LED indicator **1** or lower LED indicator **2** lights up to indicate the direction in which the crosshead can be moved.

2

Pressing the jog up button ④ and jog down button ⑤ moves the crosshead up and down, respectively.

The crosshead moves only when the button is held down. Releasing the button stops the movement.

3

Turning the jog dial ⑥ moves the crosshead up or down.

Turning the dial clockwise moves the crosshead up, and turning counterclockwise moves it down.



**Hint** Turning the jog dial rapidly moves the crosshead faster.



**NOTE** • Keep an eye on the test space during operation although the following safety functions are activated.

- Crosshead limit
- Emergency stop switch
- Safety support functions (contact detect function and overload/underload detection function)

Although the safety functions are one of the protection mechanisms, they may not completely prevent danger due to overshooting in high-speed operation. The safety functions do not guarantee prevention of collision or overload of the crosshead or load cell.

- Do not use the safety functions for positioning or other forms of control.

### 3.4.2 Performing Crosshead Origin Return with Return Operation

In the return operation, the crosshead moves rapidly to the origin (where the position value is 0).

#### CAUTION



Instruction

The crosshead moves rapidly during return operation or offset based on the registered distance between jigs. Keep hands away from the moving part. Be careful to prevent the jigs from interfering with nearby objects.

- An operator may get his/her hand caught, resulting in injury, or nearby objects may be damaged.
- Immediately press the emergency stop switch if the instrument movement is abnormal.



Instruction

The crosshead moves rapidly during return operation or offset based on the registered distance between jigs. Be sure to check the arrow direction displayed on the operation controller and smart controller before starting the return operation.

Otherwise an operator may touch the crosshead and get injured.

1

For the operation controller, press the return button, and for the smart controller, press [Return Home].



The direction, speed, and distance of return operation are displayed.

2


Check the displayed information and press [Move].

The crosshead moves to the origin.

- NOTE**
- The return operation is not available in the manual mode.
  - Keep an eye on the test space during operation although the following safety functions are activated.
    - Crosshead limit
    - Emergency stop switch
    - Safety support functions (contact detect function and overload/underload detection function)
 Although the safety functions are one of the protection mechanisms, they may not completely prevent danger due to overshooting in high-speed operation. The safety functions do not guarantee prevention of collision or overload of the crosshead or load cell.
  - Do not use the safety functions for positioning or other forms of control.

### 3.4.3 Switching the Jog Speed

- 1 Press the manual button on the operation controller or the smart controller. The instrument is set to the manual mode.
- 2 Select the desired jog speed from the options displayed in the speed table.





**Hint** The contact detect is a function to monitor the test force during jog operation, stopping the crosshead in case of any sudden change in the test force.

### 3.4.4 Registering the Jog Speed, Jog Dial Max. Speed, and Return Speed

#### ■ Registering the Jog Speed and Jog Dial Max. Speed

- 1 For the operation controller, go to [Settings] - [Customize] - [Jog speed] from the main screen. For the smart controller, go to [Set] - [Setting 1] - [Speed]. The jog speed and the jog dial max. speed currently registered are displayed.





## 2 Enter the desired value to the jog speed and the jog dial max. speed.

- Hint**
- Up to 50 mm/min can be registered to [Jog speed 01].
  - The values must satisfy [Jog speed 01] < [Jog speed 02] < [Jog speed 03].
  - The values that can be registered in [Jog speed 03] and [Jog dial Max. speed] are limited up to the maximum test speed of the testing machine.



## 3 Press [OK].

The jog speed and the jog dial max. speed are registered.

### ■ Registering the Return Speed

## 1 For the operation controller, go to [Settings] - [Testing machine] - [Return speed] from the main screen. For the smart controller, go to [Set] - [Setting 1] - [Speed].

The return speed currently registered is displayed.



## 2 Enter the desired value to the return speed.

- Hint**
- The value that can be registered in [Return speed] is limited up to the maximum return speed of the testing machine.

## 3 Press [OK].

The return speed is registered.

### 3.4.5 Changing the Distance Between Jigs

#### **CAUTION**



Instruction

Keep hands away from the moving part since the crosshead moves rapidly during return or offset based on the registered distance between jigs. Be careful to prevent the jigs from interfering with nearby objects.

An operator may get his/her hand caught, resulting in injury, or nearby objects may be damaged.

Immediately press the emergency stop button if the instrument movement is abnormal.



Instruction

The crosshead moves rapidly during return or offset based on the registered distance between jigs.

Be sure to check the arrow direction displayed on the controller before starting the return movement.

Otherwise an operator may touch the crosshead and get injured.

The function is to move the crosshead to keep the registered distance between jigs.





NOTE

Since the jig weight is measured, change the distance between the jig when the test force measurement is stable more than 15 minutes after the load cell is energized.

#### ■ Registering the Distance Between Jigs



1

Press [Inter-jig distance] on the touch panel.



2



Press [Ini. settings].



3

3

Input in [Current jig dist.] ① (actually measured value) and [Max.]/[Min.] ② (upper/lower limit values) and press [OK] ③.





The range where the crosshead can move is determined by the specified upper/lower limit values ②.

- NOTE**
- Jig weight is used to determine which jig is installed. To measure jig weight, perform the test at least 15 minutes after the load cell is energized and the test force measurement is stable. If the test force measurement value is not stable, it will be identified as a different jig and a warning screen will be displayed when distance movement between jigs is performed.
  - To make the initial setting of distance between jigs, measure and input accurate values at the time of setting. If inaccurate values are input, the jigs may interfere with each other.
  - After the jigs are changed, be sure to make the initial setting of distance between jigs. Otherwise the jigs may interfere with each other.
  - [Min.] can be set to 20 mm or more in the tension test mode. [Min.] can be set to 0 mm or more in the compression/three-point/four-point bending test mode.

## ■ Offset Based on the Distance Between Jigs

**1**

Input the distance between jigs in [Inter-jig distance] ① and press [Move] ②.



**3**

2



The weight of the current jig is automatically measured and compared with the jig weight at the time of the registration of the distance between jigs. If there is a difference in weight, a warning screen is displayed because a different jig may be installed.

If there is no weight difference, no warning screen is displayed. Proceed to the next section. If a warning screen is displayed, follow the steps below.

- 1 If the jig installed in the tester is the same as the jig used to register the distance between jigs, press [OK]. If not, press [Cancel]. The offset based on the distance between jigs will not be performed.





- 2 Confirm that the actual distance between jigs matches the [Current jig distance] displayed on the screen, then press [OK]. The current jig weight is re-registered and the offset function becomes available. If they do not match, press [Cancel]. The offset based on the distance between jigs will not be performed.



**NOTE** Even when using the same jig, this warning screen may be displayed due to unstable test force measurement values or changes in the surrounding environment (such as temperature drift on the load cell).

3

The screen for starting the offset based on the distance between jigs is displayed. Confirm the direction and distance of the movement and press [Move].



3

The crosshead starts offset based on the registered distance between jigs.

**NOTE** Keep an eye on the test space during operation although the following safety functions are activated.

- Crosshead limit switch
- Emergency stop switch
- Safety functions ("TouchLoad" function and overload detection function))

Although each of the safety functions works as a protection system, it may not completely prevent danger due to overshooting in high-speed operation.



The safety functions do not guarantee prevention of collision or overloading in the test space.

Do not use the safety functions for positioning or control.



▶▶ Reference ["3.5 Configuring/Checking the Safety Devices" P.57](#)

■ Deletion of Registered Distance Between Jigs

1 Press [Ini. settings].



2 Press [Delete] ① and then [OK] ②.



The registered distance between jigs is deleted.



## 3.5 Configuring/Checking the Safety Devices

Before starting a test, be sure to configure and check the following safety devices.

- Hint** The limit switches to limit the movable range of the crosshead include the following types. Set the limit switches depending on the purpose.
- Crosshead Limit Switches: Limits to be set according to the jigs used (See 3.5.1.)
  - Software limits: Limits to be set according to the test content or the size of a specimen (See 3.5.4.)
  - Upper/lower limits of distance between jigs: Limits to be set to prevent misoperation during the offset based on the registered distance between jigs (See 3.4.5.)


### 3.5.1 Crosshead Limit Switch

The switches limit the movable range of the crosshead. Specify the upper and lower limits of the movable range so that the power to the motor is cut to forcibly stop the crosshead when the crosshead reaches either of the limits.


#### ■ Setting the Crosshead Limit Switches

Set the crosshead upper limit **1** and crosshead lower limit **2** to the positions of the upper and lower limits of the crosshead movement **3**. Set them to the positions where collision between the attached jigs can be prevented.

table-top type




floor type



■ Changing the Positions of the Crosshead Limit Switches


**Table-top type**

Press and hold the middle part of the crosshead limit switch ① and slide it up or down to change the position. Release the crosshead limit switch to fix it at the desired position.



**Crosshead limit switch for floor type with 600 kN**

Pinch the knobs of the crosshead limit switch ① and slide it up or down to change the position. Release the knobs of the crosshead limit switch to fix it at the desired position.



**⚠ CAUTION**



Prohibition

Do NOT use the crosshead upper and lower limit switches as a condition to end a test.

A jig may hit and damage the frame, another jig or the load cell, which may result in injury of an operator.



Instruction

Specify the estimated movable range of the crosshead correctly with the crosshead upper and lower limit switches.

A jig may hit and damage the frame, another jig or the load cell, which may result in injury of an operator.



Instruction

The crosshead limit switches stop within 5 mm from the set positions. Set the positions of the crosshead limit switches to a position 5 mm away from the position where you desire to stop the crosshead limit switches.

Otherwise the jigs may interfere with each other.

▣ NOTE

- Specify the range that can prevent the jig on the crosshead from interfering with the yoke or the jig on the table when the crosshead moves up or down.
- If you have any difficulty in limiting the range, at least specify the range by keeping 20 mm or more clearance between the grips.
- After fixing the crosshead upper and lower limit switches, try to move them up or down to check for slippage.

### ■ When the Crosshead Limit Is Detected

An error message is displayed on the LCD touch panel of the smart controller.

1

Release the alarm on the computer software, operation controller, or smart controller.

2

Press  (standby button) on the front side of the control box and AGX-V/R controller.

3


Retract the crosshead using the jog operation on the operation controller or the smart controller.

**NOTE** Jog operation is available only in the direction of the crosshead limit release.

**Hint** In the manual mode, the LED indicator for the direction in which the crosshead can move will light up.

4

Press the jog button  to release the crosshead limit switch.




## 3.5.2 Protection Cover

The protection cover ❶ is designed to prevent fragments of a broken specimen from scattering around the area.

Close the cover before starting a test. Opening the cover during a test or return activates the interlock, an alarm is displayed, and the crosshead stops.

- ▼ **NOTE**
- To check the interlock function, open and close the protection cover once or more times after a test ends.
  - The jog dial operation can be performed even when the protection cover is open.
  - The jog up/down operation can be performed at a speed of 50 mm/min or less even when the protection cover is open.



### 3.5.3 Emergency Stop Switch

Use the switch to stop the crosshead in an emergency. Pressing the emergency stop switch ❶ cuts power to the motor and forcibly stops the crosshead. To release the switch, turn the control part in the arrow direction.

Emergency stop switch  
(enlarged)






Table-top type



Floor type



**NOTE** The reinforced yoke model comes with an additional emergency stop switch to be attached to the testing machine pole. Install the switch in a position accessible during testing or return operation.  
The wide model with protection cover comes with a tabletop emergency stop switch.  
Place the switch in a position accessible when the protection cover is open.

### 3.5.4 Software Limits

Set software limits to trigger an alarm and stop the crosshead when the measured value exceeds a specified value during a test. With the special software TRAPEZIUMX-V, maximum and minimum limit values can be set for all connected sensors (stroke/test force/optional additional sensors) individually.

▶▶ Reference "TRAPEZIUMX-V User Guide"

## 3.6 Safety Support Functions

### 3.6.1 Contact Detect Function

With this function, the crosshead will stop if the load cell detects a load fluctuation over a certain level during return operation, an offset based on the registered distance between jigs, or jog operation (except for jog dial operation). The function helps prevent malfunctions and injuries due to collisions between jigs and pinching of fingers.

#### ■ Contact Detect Sensitivity

- 300 kN < Load cell rating: 0.01 % of load cell rating
- 100 kN < Load cell rating ≤ 300 kN: 0.02 % of load cell rating
- 50 kN < Load cell rating ≤ 100 kN: 0.04 % of load cell rating
- 1 kN < Load cell rating ≤ 50 kN: 0.1 % of load cell rating
- 100 N < Load cell rating ≤ 1 kN: 1 % of load cell rating
- Load cell rating ≤ 100 N: Not detected

- ▼ **NOTE**
- This function does not prevent collisions between jigs or pinching of fingers.
  - This function does not prevent overloading of the test force.
  - The contact detect function does not work in the jog dial operation.
  - The contact detect function will not work when the rating of the connected load cell is 100 N or lower.

### ■ Contact Detect Direction

Test Conditions	Test Starting Direction	Crosshead Operation Direction	Contact Detect Direction
Tension	Up	Up	Test force change in positive direction
		Down	Test force change in negative direction
	Down	Up	Test force change in negative direction
		Down	Test force change in positive direction
Compression	Up	Up	Test force change in positive direction
		Down	Test force change in negative direction
	Down	Up	Test force change in negative direction
		Down	Test force change in positive direction

- ▼ **NOTE**
- To prevent false detection due to inertial force, contact detect is not detected for one second after the start of crosshead operation.
  - No contact detect is detected when the crosshead is moved in the test force unloading direction.  
The contact detect function starts to operate when the test force goes below zero and the test force starts to increase in the negative direction.

## 3.6.2 Overload/Underload Detection Function

### ■ Overload/Underload Detection

The crosshead stops when the test force as described below is detected.

- When the test force reading exceeds the  $\pm 102\%$  of the load cell rating
- When the measured test force (a value without zero offset) exceeds  $\pm 150\%$  of the load cell rating

- NOTE**
- This function does not prevent collisions between jigs or pinching of fingers.
  - This function may not prevent occasional damage to the jig or load cell.

### ■ When Overload/Underload is Detected

1

Release the alarm on the computer software, operation controller, or smart controller.

2

Press  (standby button) on the front side of the control box or AGX-V/R controller.

3

Move the crosshead with jog operation on the operation controller or smart controller to unload the test force.

- NOTE**
- Jog operation is available only in the test force unloading direction.
  - Set the test type, load cell polarity, and movement direction correctly according to the test subject. Otherwise, it may become impossible to unload the test force.



**Hint** If overload/underload status cannot be released, remove the load cell cable from the CAL connector, and perform zero reset of the test force.



## 3.7 Starting/Ending a Test

### WARNING



Prohibition

**Do NOT place jigs on the rear cover.**

If you put your body into the test space, your body may get caught in the jig and get injured.



Instruction

**If your testing machine does not have a protection cover, keep face or other body parts away from a specimen during a test.**

Fragments of a fractured specimen may scatter and damage your eyes and body. Wear protective glasses, install a cover, etc., for possible scattering of fractured specimen.

### CAUTION



Instruction

**Wear protective gloves when replacing jigs, installing or removing the specimen.**

- The jig may pinch your fingers and cause injury.
- Your hand may slip when applying force, causing injury to your fingers.
- Your fingers may contact the fractured surface of the specimen and get injured.

### 3.7.1 Starting a Test

Create test conditions using the operation controller or the computer software TRAPEZIUMX-V and attach a specimen. Now the test can be started.


- To set test conditions
  - ▶▶ Reference • "Operation Controller Instruction Manual" (Document No.: 349-11595)
  - "Shimadzu Autograph Software TRAPEZIUM X-V User Guide" (Document No.: 349-08931)
- To attach a specimen
  - ▶▶ Reference "Precision Universal Testing Machines AUTOGRAPH AGX-V2 Series Reference Manual" (Document No.: 349-11986)

Before starting a test, configure and check the safety devices again. A test can be started with the operation controller, smart controller, or computer software TRAPEZIUMX-V.

#### ■ For Operation Controller or Smart Controller

1

Press the start button for the operation controller, or [Start test] for the smart controller.



The screen displays the direction, speed, and distance of the test operation.


2

Confirm the displayed information, and press [Start test].

The test operation starts.


## ■ For the Computer Software TRAPEZIUMX-V

### 1 Press [Start Test].



The screen displays the direction, speed, and distance of the test operation.

### 2 Press [Start].



The test operation starts.

### 3.7.2 Ending a Test

If the test end conditions have been set with the operation controller or the computer software TRAPEZIUMX-V, a test ends when the conditions are satisfied.

To end a test manually, use the operation controller, smart controller, or computer software TRAPEZIUMX-V.

#### ■ For Operation Controller

- 1 Press the Stop button.



The test is ended.

#### ■ For Smart Controller

- 1 Press [Stop test].




The test is ended.

## ■ For the Computer Software TRAPEZIUMX-V

1

Press [Stops the test].



The test is ended.

3

# 4

## Performance Inspection and Maintenance

### 4.1 Periodic Inspection

Shimadzu offers periodic inspection services so that you can benefit from stable performance of your instrument for a long time.

To ensure traceability, it is recommended to have your instrument inspected/serviced once a year.

Service personnel trained by us will visit your site and perform inspection/checkup according to documents provided by us.

Shimadzu also offers validation services according to official standards as well. For more information, contact your Shimadzu representative.

We do not guarantee the product performance if repairs or modifications have been performed by parties other than Shimadzu representative.

#### CAUTION



A person with necessary expertise should perform wiring, maintenance and inspection.

Otherwise an electric shock, injury or fire may occur.

### 4.2 Regular Inspection List

The list below shows the points to be inspected regularly and the recommended inspection frequencies. Perform regular inspection as shown in the list below to ensure safety and precision of the instrument.

Items to be inspected		Before work	3 months	6 months	1 year	Reference
Inspection of Safety Device	Emergency Stop Switch	-	✓	-	-	P.71
	Crosshead Limit	-	✓	-	-	P.71
	Protection Cover	-	✓	-	-	P.72
Checking the Test Force		✓	-	-	-	P.73
Checking the Stroke Speed		-	-	✓	-	P.75
Greasing the Ball Screws		-	-	-	✓	P.76
Greasing the Guide Poles		-	-	-	✓	P.77
Replacing the Cooling Fan Filter		-	-	✓	-	P.78

## 4.3 Inspection of Safety Devices

If any of the following parts do not operate in inspection, contact your Shimadzu representative. We do not guarantee the product performance if repairs or modifications have been performed by parties other than Shimadzu representative.

### 4.3.1 Emergency Stop Switch

▶▶ Reference "3.5.3 Emergency Stop Switch" P.61

- 1 While operating the crosshead in the jog operation, press the emergency stop switch.

▣ NOTE Set the jog speed to 500 mm/min or less.

- 2 Check that the crosshead stops and does not start again even if you tried to continue to move it in the jog operation.

- 3 Turn the control part of the emergency stop switch in the arrow direction to release.

### 4.3.2 Crosshead Limit Switch

▶▶ Reference "3.5.1 Crosshead Limit Switch" P.57

- 1 Set the crosshead upper limit at 20 mm to 30 mm above the crosshead and move the crosshead upward with the jog up button.

- 2 Check that the crosshead stops when it pushes up the crosshead upper limit and does not start moving even if you continue to press the jog up button.

- 3 Release the crosshead upper limit and move the upper limit to the upper position.




- 4 Set the crosshead lower limit at 20 mm to 30 mm below the crosshead and move the crosshead downward with the jog down button.

- 5 Check that the crosshead stops when it pushes down the crosshead lower limit and does not start moving even if you continue to press the jog down button.

- 6 Release the crosshead lower limit and move the lower limit to the lower position.

### 4.3.3 Protection Cover

▶▶ Reference "3.5.2 Protection Cover" P.60

- 1 On the main screen of the smart controller or operation controller, press  (zero reset) of [Position] to set the position value to 0.
- 2 Check that the jigs do not interfere with nearby objects and press the jog up/down button to move the crosshead.
- 3 While the protection cover is open, press  (return) on the smart controller or operation controller.
- 4 Check that an interlock alarm is displayed and the crosshead does not move.
- 5 Clear the alarm and close the protection cover.
- 6 Press  (return) on the smart controller to return the crosshead or operation controller.
- 7 While return is in progress, open the protection cover.
- 8 Check that an interlock alarm is displayed and the crosshead stops.
- 9 Clear the alarm and close the protection cover.



10

Press  (return) on the smart controller or operation controller to return the crosshead.

### WARNING



Instruction

Keep hands away from the moving part since the crosshead moves rapidly during return to origin. Be careful to prevent the jigs from interfering with nearby objects.

A hand of an operator may be caught, resulting in injury.



**Hint** Immediately press the emergency stop button if the instrument movement is abnormal.

## 4.4 Checking the Test Force

### CAUTION



Instruction

**Wear safety shoes when checking the test force.**

The weight may fall on your feet and cause injury.

Use light weights to simply check whether the test force is almost correct.

(The following values are an example.)

Use a 100 N weight for 1 kN to 10 kN load cells and a 50 N weight for 100 N to 500 N load cells respectively to check displayed test force.

1

**Prepare the jigs for checking test force.**

- ▶▶ Reference "Precision Universal Testing Machines AUTOGRAPH AGX-V2 Series Reference Manual" (Document No.: 349-11986)

**2** Insert the UJ joint **2** into the hole at the bottom of the tensile joint **1** and fix it with a pin.


**3** Perform E-CAL (electronic calibration).  
 ▶▶ Reference "3.3 Setting Up the Instrument" P.39

**4** Start the special software TRAPEZIUMX-V, and display the test screen for the tension test condition.  
 ▶▶ Reference "TRAPEZIUMX-V User Guide"

**5** Press on the weight hook **3** by hand to check that the test force displayed in TRAPEZIUMX-V increases.

**6** After performing zero reset, carefully set a weight **4**.



**7** Check that the displayed test force is within the following allowable error range.



Allowable Errors	<ul style="list-style-type: none"> <li>• Standard-precision unit: Within <math>\pm 1</math> % of the indicated value</li> <li>• High-precision unit: Within <math>\pm 0.5</math> % of the indicated value</li> </ul>
------------------	--

▾ **NOTE** If the weight to be set is not supported by the load cell, compare the displayed value with that of the previous check to check that the errors do not greatly vary.

## 4.5 Checking the Stroke Speed

- 1 Press the manual button on the smart controller or operation controller to turn on the manual mode and record the current jog speed.
- 2 On the [Jog speed] setting screen, set the jog speed to 10 mm/min.  
▶▶ Reference "3.4.3 Switching the Jog Speed" P.48
- 3 On the main screen, press  (zero reset) of [Stroke] to set the stroke value to 0.
- 4 Start the stopwatch when the stroke value becomes 5 mm and stop it when the stroke value becomes 15 mm.
- 5 Check the time measured with the stopwatch. The normal value is  $60 \pm 0.26$  seconds.  
 **Hint** The above value is based on the assumption that the error of stopwatch operation is 0.2 seconds.
- 6 On the [Jog speed] setting screen, return the jog speed to an original value. If the speed is abnormal, contact your Shimadzu representative.

## 4.6 Maintenance

### 4.6.1 Maintaining the Ball Screws

1


#### Prepare grease and grease gun.

- Grease:  
Alvania EP2 cartridge from Shell Lubricants Japan (P/N: S339-89306-21)
- Grease gun:  
Grease gun CH400 from THK (P/N: S339-89108-01)

- NOTE
- Do not use any molybdenum disulfide grease.  
The ball screws and ball nut will be shaved, causing backlash to occur.
  - The grease gun above is exclusively for the AGX-V2 series and AGX-V, AG-X/AG-Xplus Retrofit.

2

#### Grease the grease nipples ① located on the ball screw nuts of the crosshead with a grease gun.



- NOTE The appearance of the testing machine varies depending on its type and capacity. The testing machine shown in the figure is AGX-300kNVS.

## 4.6.2 Maintaining the Guide Poles

### **!** DANGER



Instruction

Turn off the power before opening the ball screw protection cover.

Also, be sure to close the ball screw protection cover before turning on the power.


Being caught by the rotating ball screw may result in serious injury or death.

For "table-top" testing machines, regularly grease the guide poles.

- Grease name: Molybdenum disulfide lithium-based grease  
Moly LG grease #2 from Sumico Lubricant  
(P/N : S017-27014-05)
- Greasing frequency: Every 6 months



**Hint** Greasing is not necessary for "floor type".




Regularly grease the guide bush **2** of the crosshead **1** to keep the point **3** lubricated.




**NOTE** Turn off the power before opening the protection cover of ball screws **4**. Also, be sure to close the ball screw protection cover before turning on the power.

### 4.6.3 Replacing the Cooling Fan Filter (Only AGX-V2S Series)

- 1 Hook your fingers on the upper side of the filter cover ❶ and pull it toward you.



- 2 Replace the cooling fan filter ❷ with a new one.



- 3 Attach the filter cover ❶ to the filter guard ❸.

## 4.6.4 Cleaning the Operation Unit

The smart controller and operation controller should be maintained in the following ways:

- Operation buttons  
Wipe with a soft cloth dampened with water.
- LCD Touch Panel  
Lightly wipe with a dry soft cloth or a soft cloth dampened with neutral detergent.
- Case  
Wipe with a dry soft cloth or a soft cloth dampened with neutral detergent.

Voice control devices should be maintained in the following ways:

- Body  
Wipe off gently with a dry soft cloth.
- Microphone hole  
Remove dust if it sticks.
- Stand  
Gently wipe with a dry soft cloth or a soft cloth dampened with a mild detergent, then wipe dry.

**NOTE** Do not let moisture get inside. The device may malfunction.

## 4.6.5 Cleaning the Instrument

- Table surface  
Wipe off dirt with a dry soft cloth or a soft cloth dampened with neutral detergent. Then apply antirust oil to the metal surface with a cloth.
- Top and bottom surfaces of the crosshead  
Wipe off dirt with a dry soft cloth or a soft cloth dampened with neutral detergent. Then apply antirust oil to the metal surface with a cloth.
- Other casing  
Wipe with a dry soft cloth or a soft cloth dampened with neutral detergent.

The voice control device should be maintained in the following ways:

- Body  
Wipe off gently with a dry soft cloth.
- Microphone hole  
Remove any dust that adheres to the surface.
- Stand  
Gently wipe with a dry soft cloth or a soft cloth dampened with a mild detergent, then wipe dry.

**NOTE** Do not let any moisture get inside. The device may malfunction.


## 4.7 Usage Time/Counts


This instrument has the functions to always monitor time/number of times that the testing machine is used and notify the operator of the information to when a specified value is reached.

"Usage Time Notification Screen" is displayed when a specified value is reached. Although no urgent abnormality has occurred in the testing machine, the testing machine is at high risk of equipment failure. Contact your Shimadzu representative for inspection. The current usage time/count can be checked, so that the operator can identify the proper timing for maintenance of the testing machine.

▶▶ Reference "4.7.2 Checking Usage Time/Counts" P.84

**NOTE** Close the usage time notification screen to use the testing machine as normal; however, the testing machine is at high risk of equipment failure. Contact your Shimadzu representative for inspection.

**Hint** The  icon is displayed in the status display area on the test screen when there is any item whose specified value is reached. Press the icon to display the usage time notification screen again.




Usage Time Notification Screen




Status Display When a Specified Time Is Reached





Usage Time Notification Screen



Status Display When a Specified Time Is Reached

4

### 4.7.1 Notification Item

The testing machine provides notification when a specified value of the items listed in the table below is reached.


Notification item	Description
First Date of Use	The first date that the testing machine was used is recorded. The testing machine provides notification when the number of years elapsed from the first date reaches the specified value.
Powering Time	Displays the total time while the testing machine was powered. The testing machine provides notification when the specified time is reached.
Motor On Time	Displays the time while the servo amplifier was set. The testing machine provides notification when the specified time is reached.
Motor Servo On Time	Displays the time while the servo amplifier was on. The testing machine provides notification when the specified time is reached.
Crosshead Travel Distance	Displays the total travel distance of the crosshead. The testing machine provides notification when the specified distance is reached.
Emergency Stop Count	Displays the number of times that the emergency stop alarm was triggered. The testing machine provides notification when the specified count is reached.
Over Upper Stroke Limit Count	Displays the number of times that the over upper stroke limit alarm was triggered. The testing machine provides notification when the specified count is reached.
Over Lower Stroke Limit Count	Displays the number of times that the over lower stroke limit alarm was triggered. The testing machine provides notification when the specified count is reached.
LCD Backlight Lighting Time	Displays the time while the LCD backlight for the smart controller or operation controller lighted. The testing machine provides notification when the specified time is reached.
Key Switch Operation Count	Displays the number of times of operating the manual switch, up switch, or down switch on the smart controller or operation controller, whichever was most frequently used. The testing machine provides notification when the specified count is reached.
Jog Dial Count	Displays the jog dial encoder pulse count on the smart controller or operation controller. The testing machine provides notification when the specified count is reached.
LCD Touch Panel Operation Count	Displays the number of times that the LCD touch panel of the smart controller or operation controller was operated. The testing machine provides notification when the specified count is reached.

Notification item	Description
Protection Cover Operation Count	<p>(Only when the testing machine is equipped with the protection cover) Displays the number of times that the protection cover was opened and closed. The testing machine provides notification when the specified count is reached.</p> <div style="border: 1px solid black; padding: 5px;"> <p>▼ <b>NOTE</b> When the Option is switched ON/OFF, the use count and limit count are reset.</p> </div>
Grip Operation Count	<p>(Only when the testing machine is equipped with the hydraulic grips) Displays the number of times of opening/closing the upper or lower chuck of the hydraulic grips, whichever was more frequently used.</p> <div style="border: 1px solid black; padding: 5px;"> <p>▼ <b>NOTE</b> When the Option is switched ON/OFF, the use count and limit count are reset.</p> </div>
Fan Stop	<p>The testing machine provides notification when speed of the cooling fan incorporated in the testing machine drops to the specified value or less.</p> <div style="border: 1px solid black; padding: 5px;"> <p>▼ <b>NOTE</b> The servo alarm may be triggered depending on the circumstance that the testing machine is used. Contact your Shimadzu representative.</p> </div>
Filter Replacement	<p>Displays the usage time of the filter of the cooling fan installed on the AGX-V/R controller for the AGX-V2S series and AGX-V/R controller. The testing machine provides notification when the usage time reaches the specified time. Replace the filter when notified. After replacing the filter, reset the usage time in "<a href="#">4.6.3 Replacing the Cooling Fan Filter (Only AGX-V2S Series)</a>".</p> <p>▶▶ <b>Reference</b> For how to replace the filter, refer to "<a href="#">4.6.3 Replacing the Cooling Fan Filter (Only AGX-V2S Series)</a>" P.78</p>

## 4.7.2 Checking Usage Time/Counts

Take the following steps to check the current usage time/counts and the specified values for notification.



- 1 Press [Settings], and then [Usage time] in the [Info] tab on the smart controller screen.



The current usage time/counts and the specified values for notification are displayed.

2

Use the page selector button ⑤ to display the notification item to check.



No.	Description
①	Displays the current status. Normal : There is no item that the specified value is reached. Run an inspection. : There is at least an item that the specified value is reached.
②	Item name for the usage time/count that triggers notification ▶▶ Reference "4.7.1 Notification Item" P.82
③	The current usage time/count The figure is displayed in red if the specified value is reached.
④	Value of the specified time/count that notification is to be provided when it is reached. "Usage Time Notification Screen" is displayed when the current usage time/count reaches this specified value.
⑤	Page selector button
⑥	Used to close the screen.

# 5 Troubleshooting

## 5.1 Introduction

This chapter explains how to address system errors and gives examples of problems. Before deciding that your instrument has failed, consult this chapter for the content that may solve your problem.


If any abnormality other than examples in this chapter has occurred, contact Shimadzu factory, your Shimadzu representative. We do not guarantee the product performance if repairs or modifications have been performed by parties other than Shimadzu or your Shimadzu representative.

## 5.2 Alarm Display

### 5.2.1 Alarm Display

When the instrument has detected an error, an alarm message is displayed on the LCD touch panel of the smart controller and on the screen of the special software TRAPEZIUMX-V.

See an example of the special software TRAPEZIUMX-V display as below.



Alarm messages and corresponding measures are shown in the table of "5.2.2 Alarm Code List" P.87.

While an alarm is displayed, the crosshead stops and the screen cannot be changed. Read the alarm content carefully, clear the alarm display and perform the recovery measure.

**NOTE** If a computer is connected, an error cannot be cleared from the LCD touch panel of the smart controller. Press the [Reset] button shown on the TRAPEZIUMX-V screen of the computer.

## 5.2.2 Alarm Code List

**NOTE** If any error code other than those listed below is displayed, hardware failure other than system errors should also be considered. Contact your Shimadzu representative.

The "#" symbol in the table represents numbers 1 to 6.

CODE	Alarm Display	Measure
1	Initialization Error CPU2 System Error Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
2	Initialization Error EEP-ROM Error (PF) Restart Instrument.	
3	Initialization Error Peripheral Device Error Restart Instrument.	
4	Initialization Error Operation Unit Unconnected Restart Instrument.	<ul style="list-style-type: none"> <li>• Check connection of the smart controller or operation controller.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
5	Initialization Error CPU1 Startup Error Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
6	Initialization Error CPU1 Communication Error Restart Instrument.	
7	Initialization Error DIP Switch Read Error (PF) Restart Instrument.	
8	Initialization Error Load Inconsistency Error Restart Instrument.	
9	Initialization Error Operation Unit Data Set Restart Instrument.	
10	Initialization Error Absolute Position Read Restart Instrument.	
11	Initialization Error Stroke Information Restart Instrument.	
12	Initialization Error Internal Unit Information Restart Instrument.	

CODE	Alarm Display	Measure
101	Emergency Stop Alarm (External) Check Safety and Release Switch.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Release the emergency stop switch of the operation controller.</li> <li>• Check connection of the smart controller or operation controller.</li> </ul>
102	Emergency Stop Alarm (Internal) Check Safety and Release Switch.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Release the emergency stop switch of the instrument.</li> </ul>
201	Crosshead Upper Limit Check Safety and Release Upper Limit Switch.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Release the crosshead upper limit of the instrument.</li> <li>• You can also press the standby button to power the motor and lower the crosshead in the jog operation.</li> </ul>
202	Crosshead Lower Limit Check Safety and Release Lower Limit Switch.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Release the crosshead lower limit of the instrument.</li> <li>• You can also press the standby button to power the motor and raise the crosshead in the jog operation.</li> </ul>
203	Crosshead Limit Sensor Alarm Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
210	Crosshead Limit Check Safety and Release Limit Switch.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Release the crosshead limit of the instrument.</li> </ul>
301	System Voltage Error 24 V Power Supply Voltage Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
302	System Voltage Error 12 V Power Supply Voltage Restart Instrument.	
303	System Voltage Error +15 V Power Supply Voltage Restart Instrument.	
304	System Voltage Error -15 V Power Supply Voltage Restart Instrument.	
305	System Voltage Error SV-VIN1 Input Voltage Restart Instrument.	
306	System Voltage Error SV-VIN2 Input Voltage Restart Instrument.	



CODE	Alarm Display	Measure
307	System Voltage Error USB-VBUS0 Input Voltage Restart Instrument.	<ul style="list-style-type: none"> <li>• Disconnect the devices connected to the USB connectors.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
308	System Voltage Error USB-VBUS1 Input Voltage Restart Instrument.	
400	Return Execution Error Perform "Position zero".	Press the position zero button of the smart controller, operation controller or the computer software.
501	Distance Between Jigs Error Set initial value for Inter-jig distance.	Open the distance between jigs setting screen of the smart controller, operation controller or the computer software and register the current distance between jigs.
502	Distance Between Jigs Error This is not a registered jig.	Check that the registered jig/load cell used for registration is connected.
900	Servo Off The motor power is off. Press the standby button.	Press the standby button to power the motor.
1000	Servo Startup Error Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
1101	Servo Alarm I/F Wiring Error (000) An alarm has gone off in the servo amplifier.	
1102	Servo Alarm Current Error (001) An alarm has gone off in the servo amplifier.	
1103	Servo Alarm Overload/Temp. Error (010) An alarm has gone off in the servo amplifier.	
1104	Servo Alarm Power Supply Error (011) An alarm has gone off in the servo amplifier.	
		<ul style="list-style-type: none"> <li>• Check that the power supply voltage to the instrument is within <math>\pm 10</math> % of the rated value.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>

CODE	Alarm Display	Measure
1105	Servo Alarm Motor Encoder Wiring (100) An alarm has gone off in the servo amplifier.	
1106	Servo Alarm Motor Encoder Error (101) An alarm has gone off in the servo amplifier.	
1107	Servo Alarm Overspeed/Deviation (110) An alarm has gone off in the servo amplifier.	
1108	Servo Alarm Memory Error (111) An alarm has gone off in the servo amplifier.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
1109	Servo Alarm SET Error An alarm has gone off in the servo amplifier.	
1110	Servo Alarm Power On Permission Error An alarm has gone off in the servo amplifier.	
1111	Servo Alarm Servo On Error An alarm has gone off in the servo amplifier.	
1200	Computer Connection Error After Checking LAN Cable Restart Instrument.	<ul style="list-style-type: none"> <li>• Check connection of the communication cable between the instrument and computer and connection of the communication path (e.g., relay).</li> <li>• Exit the computer software and then start it again.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
1300	USB Drive Error Check Connection of USB Drive.	<ul style="list-style-type: none"> <li>• Disconnect the USB drive connected to the USB connector and connect it again.</li> <li>• Check that you are using a (validated) USB drive specified by us.</li> <li>• Check that the USB drive has been formatted to FAT16/FAT32.</li> </ul>
1401	Interlock Alarm Check Safety and Clear Interlock.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>

CODE	Alarm Display	Measure
1402	Interlock Alarm Close Protection cover.	<ul style="list-style-type: none"> <li>• Close the protection cover.</li> </ul>
1403	Interlock Alarm Open and Close Protection cover.	<ul style="list-style-type: none"> <li>• Open and close the protection cover.</li> <li>• To perform the next test in succession, open the protection cover and close it again.</li> </ul>
2000	Overrating Alarm Sensor Name (TD#) Exceeded Rated Value.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Recover the sensor from the overload.</li> </ul>
2100	Underrating Alarm Sensor Name (TD#) Exceeded Rated Value.	
2200	Software Limit Alarm Sensor Name (TD#) Reached Limit Value.	
2300	Automatic Control Alarm Controllable speed of Sensor Name (TD#) exceeded.	<ul style="list-style-type: none"> <li>• The speed of the instrument has reached the limit value.</li> <li>• Check that the test condition is correct.</li> <li>• Lower the stress or strain increasing rate.</li> </ul>
2351	Automatic Control Alarm Control calculation is not in time.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
2352	Automatic Control Alarm Control parameter out of range.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
2400	Contact Detect Alarm Force Changed and Safety Function Was Activated.	<ul style="list-style-type: none"> <li>• Check safety in the test space and its surroundings.</li> <li>• Press the standby button to power the motor.</li> </ul>
3000	CAL Connector Read Error Check the CAL connector of Sensor Name (TD#).	<ul style="list-style-type: none"> <li>• Disconnect the CAL connector connected to the displayed sensor (TD#) and connect it again.</li> </ul>
3100	CAL Connector Write Error Check the CAL connector of Sensor Name (TD#).	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
3200	Auto Zero Error Check the measured value of Sensor Name (TD#).	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>

CODE	Alarm Display	Measure
3300	F-CAL Execution Error Check the reference sensor Sensor Name (TD#) and polarity of the sensor.	<ul style="list-style-type: none"> <li>• Check that the correct CAL connector is connected to the displayed sensor (TD#).</li> <li>• Disconnect the CAL connector connected to the displayed sensor (TD#) and connect it again.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
3401	E-CAL Data Creation Error Auto Zero Failed. Try Again.	
3402	E-CAL Data Creation Error E-CAL Signal Error. Try Again.	
3404	E-CAL Data Creation Error Outside Adjustable Range. Try Again.	
3405	E-CAL Data Creation Error Adjustment Was Aborted. Try Again.	
3406	E-CAL Data Creation Error Calibration Failed. Try Again.	
3407	E-CAL Data Creation Error System Error	
3501	E-CAL Execution Error Auto Zero Failed. Try Again.	<ul style="list-style-type: none"> <li>• Check that the correct CAL connector is connected to the displayed sensor (TD#).</li> <li>• Check that the CAL connector connected to the displayed sensor (TD#) was calibrated (went through F-CAL).</li> <li>• Disconnect the CAL connector connected to the displayed sensor (TD#) and connect it again.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
3502	E-CAL Execution Error E-CAL Signal Error. Try Again.	
3503	E-CAL Execution Error E-CAL Data Error. Try Again.	
3504	E-CAL Execution Error Outside Adjustable Range. Try Again.	
3505	E-CAL Execution Error Adjustment Was Aborted. Try Again.	
3506	E-CAL Execution Error Calibration Failed. Try Again.	
3507	E-CAL Execution Error System Error	
3600	Linearize Error The calculation results were not appropriate. Try Again.	
3700	Calibration Error Check Signal of Sensor Name (TD#).	

CODE	Alarm Display	Measure
3800	E-CAL Inexecution Alarm Execute E-CAL.	Execute E-CAL of the test force sensor.
4001	Communication FPGA Error Abnormal Chip Temp.Increase Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
4002	Communication FPGA Error Inner Core Power Supply Restart Instrument.	
4003	Communication FPGA Error Inner Circuit Power Supply Restart Instrument.	
4004	Communication FPGA Error Block RAM Power Supply Restart Instrument.	
4006	Communication FPGA Error Outside Specifications Restart Instrument.	
4101	Measurement FPGA Error Abnormal Chip Temp.Increase Restart Instrument.	
4102	Measurement FPGA Error Inner Core Power Supply Restart Instrument.	
4103	Measurement FPGA Error Inner Circuit Power Supply Restart Instrument.	
4104	Measurement FPGA Error Block RAM Power Supply Restart Instrument.	
4106	Measurement FPGA Error Outside Specifications Restart Instrument.	
4201	Control FPGA Error Abnormal Chip Temp.Increase Restart Instrument.	
4202	Control FPGA Error Inner Core Power Supply Restart Instrument.	
4203	Control FPGA Error Inner Circuit Power Supply Restart Instrument.	
4204	Control FPGA Error Block RAM Power Supply Restart Instrument.	
4205	Control FPGA Error PIO Port Error Restart Instrument.	

CODE	Alarm Display	Measure
4206	Control FPGA Error Outside Specifications Restart Instrument.	<ul style="list-style-type: none"><li>• Turn off and on the instrument.</li><li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li></ul>

CODE	Alarm Display	Measure
4501	Operation Unit 1 Alarm Power Supply Voltage Error Restart Instrument.	<ul style="list-style-type: none"> <li>• Check connection of the smart controller or operation controller.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
4502	Operation Unit 1 Alarm Electronic Fuse Error Restart Instrument.	
4503	Operation Unit 1 Alarm Communication Framing Error Restart Instrument.	
4504	Operation Unit 1 Alarm Communication CRC Error Restart Instrument.	
4505	Operation Unit 1 Alarm Check Connection Cable of Operation Unit.	
4506	Operation Unit 1 Alarm Abnormal Chip Temp.Increase	
4507	Operation Unit 1 Alarm Inner Core Power Supply	
4508	Operation Unit 1 Alarm Inner Circuit Power Supply	
4509	Operation Unit 1 Alarm Block RAM Power Supply	
4510	Operation Unit 1 Alarm Platform Communication Error	
4511	Operation Unit 1 Alarm Operation Switch Connection Error	
4512	Operation Unit 1 Alarm Send FIFO Overflow	
4513	Operation Unit 1 Alarm Recieve FIFO Overflow	
4601	Operation Unit 2 Alarm Power Supply Voltage Error Restart Instrument.	
4602	Operation Unit 2 Alarm Electronic Fuse Error Restart Instrument.	
4603	Operation Unit 2 Alarm Communication Framing Error Restart Instrument.	
4604	Operation Unit 2 Alarm Communication CRC Error Restart Instrument.	
4605	Operation Unit 2 Alarm Check Connection Cable of Operation Unit.	
4606	Operation Unit 2 Alarm Abnormal Chip Temp.Increase	

CODE	Alarm Display	Measure
4607	Operation Unit 2 Alarm Inner Core Power Supply	<ul style="list-style-type: none"> <li>• Check connection of the smart controller or operation controller.</li> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
4608	Operation Unit 2 Alarm Inner Circuit Power Supply	
4609	Operation Unit 2 Alarm Block RAM Power Supply	
4610	Operation Unit 2 Alarm Platform Communication Error	
4611	Operation Unit 2 Alarm Operation Switch Connection Error	
4612	Operation Unit 2 Alarm Send FIFO Overflow	
4613	Operation Unit 2 Alarm Recieve FIFO Overflow	
4701	Operation Unit 3 Alarm Power Supply Voltage Error Restart Instrument.	
4702	Operation Unit 3 Alarm Electronic Fuse Error Restart Instrument.	
4703	Operation Unit 3 Alarm Communication Framing Error Restart Instrument.	
4704	Operation Unit 3 Alarm Communication CRC Error Restart Instrument.	
4705	Operation Unit 3 Alarm Check Connection Cable of Operation Unit.	
4706	Operation Unit 3 Alarm Abnormal Chip Temp.Increase	
4707	Operation Unit 3 Alarm Inner Core Power Supply	
4708	Operation Unit 3 Alarm Inner Circuit Power Supply	
4709	Operation Unit 3 Alarm Block RAM Power Supply	
4710	Operation Unit 3 Alarm Platform Communication Error	
4711	Operation Unit 3 Alarm Operation Switch Connection Error	
4712	Operation Unit 3 Alarm Send FIFO Overflow	
4713	Operation Unit 3 Alarm Recieve FIFO Overflow	



CODE	Alarm Display	Measure
5101	Hydraulic Power Unit Alarm Hydraulic Power Unit Is OFF.	<ul style="list-style-type: none"> <li>• Turn on the hydraulic power unit.</li> <li>• If the alarm still persists after the power is turned on, contact your Shimadzu representative.</li> </ul>
5102	Hydraulic Power Unit Alarm Oil Level Error Check Hydraulic Power Unit.	<ul style="list-style-type: none"> <li>• Check the oil level.</li> <li>• If the oil level is low, add hydraulic oil.</li> <li>• If the alarm still persists even if the oil level is higher than the reference value, contact your Shimadzu representative.</li> </ul>
5103	Hydraulic Power Unit Alarm Oil Temperature Error Check Hydraulic Power Unit.	<ul style="list-style-type: none"> <li>• Do not touch the hydraulic power unit immediately after the alarm occurred.</li> <li>• Stop the hydraulic power unit and leave it for two hours or more.</li> <li>• If the alarm still persists after the temperature of the hydraulic power unit has decreased, contact your Shimadzu representative.</li> <li>• If the oil temperature error occurs frequently, change the use frequency or use a cooling device.</li> </ul>
5104	Hydraulic Power Unit Alarm Thermal Error Check Hydraulic Power Unit.	Overload has occurred in the motor. Contact your Shimadzu representative.
5201	Voice Ctrl. Alarm Cannot set correctly.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> </ul>
5202	Voice Ctrl. Alarm An error has occurred.	<ul style="list-style-type: none"> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
6001	Parameter Error (1) Test Speed Setting Is Outside Range. Check Speed Setting.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check that the test speed setting satisfies the specifications of the instrument.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>

CODE	Alarm Display	Measure
6002	Parameter Error (1) Maximum Point Setting Is Outside Range. Check Maximum Point.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check the maximum point setting is within the effective range.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
6003	Parameter Error (1) Minimum Point Setting Is Outside Range. Check Minimum Point.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check the minimum point setting is within the effective range.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
6004	Parameter Error (1) Stroke Speed Is Outside Control Range.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• When stress or strain control is performed, check that the stress or strain increasing rate is within the effective range.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
6101	Parameter Error (2) Test Speed 1 Is Outside Range. Check Speed 1.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• Check that the test speed setting satisfies the specifications of the instrument.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>
6102	Parameter Error (2) Test Speed 2 Is Outside Range. Check Speed 2.	
6103	Parameter Error (2) Test Speed 3 Is Outside Range. Check Speed 3.	
6104	Parameter Error (2) Stroke Speed Is Outside Control Range.	<ul style="list-style-type: none"> <li>• Check the test conditions.</li> <li>• When stress or strain control is performed, check that the stress or strain increasing rate is within the effective range.</li> <li>• Check that the current configuration including the connected sensors is appropriate for the desired test.</li> </ul>

CODE	Alarm Display	Measure
7001	EEP-ROM (PF) Error EEP-ROM Init. Error Restart Instrument.	
7002	EEP-ROM (PF) Error EEP-ROM Write Error Restart Instrument.	
7003	EEP-ROM (PF) Error EEP-ROM Read Error Restart Instrument.	
7101	EEP-ROM (U1) Error EEP-ROM Init. Error Restart Instrument.	
7102	EEP-ROM (U1) Error EEP-ROM Write Error Restart Instrument.	
7103	EEP-ROM (U1) Error EEP-ROM Read Error Restart Instrument.	
7201	EEP-ROM (U2) Error EEP-ROM Init. Error Restart Instrument.	
7202	EEP-ROM (U2) Error EEP-ROM Write Error Restart Instrument.	<ul style="list-style-type: none"> <li>• Turn off and on the instrument.</li> <li>• If the error still persists after the power is turned off and on, contact your Shimadzu representative.</li> </ul>
7203	EEP-ROM (U2) Error EEP-ROM Read Error Restart Instrument.	
7301	EEP-ROM (U3) Error EEP-ROM Init. Error Restart Instrument.	
7302	EEP-ROM (U3) Error EEP-ROM Write Error Restart Instrument.	
7303	EEP-ROM (U3) Error EEP-ROM Read Error Restart Instrument.	
9000	Battery Error Clock's Battery Voltage Is Low. Replace Battery.	
9100	Load Frame Setting Error Load Frame Cannot Be Recognized. Restart Instrument.	
9900	System Error Undefined Error Restart Instrument.	

## 5.3 Other Problems

Problems without alarms and their measures are shown as below.

### 5.3.1 Problems About Power Supply

Problem	Measure
The instrument does not turn on.	Check that the breaker of the distribution board is on. Check that the power supply cable is not loose.
The leakage breaker of the instrument is activated.	There may be leakage inside the instrument. Immediately stop using the instrument and contact your Shimadzu representative.
The leakage breaker of the distribution board is activated.	There may be leakage inside the instrument. Immediately stop using the instrument and contact your Shimadzu representative.

### 5.3.2 Problems About Servo Motor

Problem	Measure
The motor does not operate.	Check that the emergency stop switch is not active. Check that the crosshead limit switches are not active. The motor does not operate while the instrument is starting up. Wait until the startup is completed.
A servo error occurs during a test.	Overload may have occurred in the motor. Check whether the instrument is used within the working limits. (Max. ten hours continuous operation, max. 1,000 repeat count, and max. three repeat cycles per minute).
A servo error occurs during movement in the jog operation.	Overload may have occurred in the motor. Check that no foreign matter is caught between the crosshead and table. Check that no foreign matter is winding around the ball screw.

### 5.3.3 Problems About Operating Panel

Problem	Measure
Some keys do not accept input.	Active keys are limited during a test or when a computer is connected. Try again after a test ends or when a computer is not connected. When a computer is connected, an error cannot be cleared from the instrument. Clear it from the computer.
No key input is accepted.	No key input is accepted while the instrument is starting up. Wait until the startup is completed.
The test force display is "- - - -".	The load cell is not recognized. Turn off the power, check that the calibration cable is connected appropriately, and turn on the power again. If the type of display is "peak value" or "break point value", the value is displayed only after a test ends.

### 5.3.4 Problems About Options

Problem	Measure
An optional device does not operate.	Check that presence of the optional device has been registered correctly. Some types of optional devices require restart of the instrument. Turn off the instrument, wait ten seconds or more, and turn on the instrument again.

#### CAUTION




Instruction

If the instrument emits abnormal odor or noise, immediately stop using the instrument, press the emergency stop switch, and disconnect the power supply cable.

## 5.4 System Reset

You can return the instrument settings to the factory default when you need to reset the system parameters to the initial values collectively or when incorrect parameter modification has disabled the instrument operation.

To return the settings to the factory default, open the setting screen by pressing [Set] ❶ on the main screen of the smart controller and press [Initialize] ❷ in the [Setting 2] tab.



- NOTE**
- After initialization, the crosshead position is reset and the test conditions and system settings are all initialized. Be sure to set them again.
  - Initialization does not clear the load cell information stored in the CAL connector.

# 6

## Maintenance Parts and Consumables

### 6.1 Maintenance Parts

#### ■ AGX-V/R controller

Part Name	Part No.	Qty	Remarks
Cooling Fan Filter* <sup>1</sup>	S042-60906-56	5	A replacement resin filter for the cooling fan.

\*1 The cooling fan on the tester expels air and does not use a filter.

### 6.2 Consumables

#### ■ Protective Items

Part Name	Part No.	Qty	Remarks
Protective Glasses* <sup>1</sup>	S086-78105-32	1	Wear these when operating the tester.
	S086-78103-01		
Protective Gloves* <sup>2</sup>	S086-78970-11	10	Wear these when replacing jigs, installing or removing the specimen.

\*1 Do not use any damaged protective glasses.

\*2 Do not use any damaged protective gloves.

#### ■ Testing Machine

Part Name	Part No.	Qty	Remarks
Grease (for ball screws)* <sup>1</sup>	S339-89306-21	1	Alvania EP2 cartridge, 400 cc
Grease (for guide poles)	S017-27014-05	1	Moly LG Grease #2, 400 g

\*1 Grease gun CH400 (P/N: S339-89108-01) is required for greasing.

# 7 References

## 7.1 Basic Specifications

### 7.1.1 Standard Model

#### ■ Table-top type

Model No.		AGX-10kNV2D	AGX-20kNV2D	AGX-50kNV2D
Maximum Capacity		10 kN	20 kN	50 kN
Testing Speed Range		0.0005 to 3000 mm/min	0.0005 to 1500 mm/min	
Testing Speed Precision* <sup>1</sup>		±0.1 %		
Return Speed		0.0005 to 3000 mm/min	0.0005 to 2000 mm/min	
Crosshead Speed and Acceptable Test Force [For all testing speeds]		10 kN	20 kN	50 kN
Frame Stiffness		60 kN/mm or more	180 kN/mm or more	
Stroke Control Resolution		12.5 nm	8.33 nm	
Effective Specimen Width		420 mm	500 mm	
Crosshead-Table Distance	Standard	180 to 1150 mm	200 to 1150 mm	
	250 mm Extension	180 to 1375 mm	200 to 1375 mm	
	500 mm Extension	180 to 1600 mm	200 to 1600 mm	
Dimensions Width × Depth × Height	Standard	798×515×1582 mm	975×579×1708 mm	
	250 mm Extension	798×515×1832 mm	975×579×1958 mm	
	500 mm Extension	798×515×2082 mm	975×579×2208 mm	
Mass	Standard	100 V	210 kg	-
		200 V	210 kg	410 kg
	250 mm Extension	100 V	230 kg	-
		200 V	220 kg	420 kg
	500 mm Extension	100 V	240 kg	-
		200 V	230 kg	440 kg
Power Requirements* <sup>2</sup>	100 V model		1.5 kVA	-
	200 V model		2.0 kVA	5.5 kVA
Breaker Capacity* <sup>3</sup>	100 V model		15 A	-
	200 V model		10 A	30 A



Model No.	AGX-10kNV2D	AGX-20kNV2D	AGX-50kNV2D
Short Circuit Rating (Icu/Ics)	2.5 kA/1.0 kA		
Short-Circuit Current Rating	1.5 kA		
Protective Conductor Current* <sup>4</sup>	0~5 mA		
Ground	Type-D* <sup>5</sup>		
Noise* <sup>6</sup>	65 dB(A)		

- \*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.
- \*2 100 V model: Single phase 100 V to 115 V, 200 V model: Single phase 200 V to 230 V. Separately prepare a power supply for a computer.
- \*3 Prepare an inverter-compatible (medium-speed) breaker.
- \*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.
- \*5 Type-D: 100  $\Omega$  or less grounding resistance.
- \*6 Measured 1 m away from the front of the machine.

## ■ Floor type

Model No.	AGX-20kNV2	AGX-50kNV2	AGX-100kNV2	AGX-300kNV2	AGX-600kNV2	
Maximum Capacity	20 kN	50 kN	100 kN	300 kN	600 kN	
Testing Speed Range	0.00005 to 1500 mm/min			0.00005 to 720 mm/min	0.00005 to 540 mm/min	
Testing Speed Precision* <sup>1</sup>	$\pm 0.1$ %					
Return Speed	0.00005 to 2000 mm/min		0.00005 to 1800 mm/min	0.00005 to 720 mm/min	0.00005 to 540 mm/min	
Crosshead Speed and Acceptable Test Force [For all testing speeds]	20 kN	50 kN	100 kN	300 kN	600 kN	
Frame Stiffness	180 kN/mm or more		300 kN/mm or more	400 kN/mm or more	700 kN/mm or more	
Stroke Control Resolution	8.33 nm			3.33 nm	2.50 nm	
Effective Specimen Width	600 mm				790 mm	
Crosshead-Table Distance	Standard	215 to 1265 mm		215 to 1250 mm	215 to 1440 mm	215 to 1650 mm
	250 mm Extension	215 to 1490 mm		215 to 1475 mm	215 to 1665 mm	215 to 1875 mm
	500 mm Extension	215 to 1715 mm		215 to 1700 mm	215 to 1890 mm	215 to 2100 mm
	750 mm Extension	215 to 1940 mm		215 to 1925 mm	215 to 2115 mm	215 to 2325 mm

## 7 References

Model No.		AGX-20kNV2	AGX-50kNV2	AGX-100kNV2	AGX-300kNV2	AGX-600kNV2
Dimensions Width × Depth × Height	Standard	1206×765×2170 mm			1206×765 ×2420 mm	1605×1122 ×2837 mm
	250 mm Extension	1206×765×2420 mm			1206×765 ×2670 mm	1605×1122 ×3087 mm
	500 mm Extension	1206×765×2670 mm			1206×765 ×2920 mm	1605×1122 ×3337 mm
	750 mm Extension	1206×765×2920 mm			1206×765 ×3170 mm	1605×1122 ×3587 mm
Mass	Standard	200 V	640 kg	780 kg	950 kg	2960 kg
		400 V	650 kg	790 kg	970 kg	-
	250 mm Extension	200 V	660 kg	810 kg	980 kg	3020 kg
		400 V	670 kg	810 kg	990 kg	-
	500 mm Extension	200 V	680 kg	830 kg	1000 kg	3070 kg
		400 V	680 kg	840 kg	1020 kg	-
	750 mm Extension	200 V	690 kg	850 kg	1030 kg	3130 kg
		400 V	700 kg	860 kg	1050 kg	-
Power Requirements* <sup>2</sup>	200 V model		4.5 kVA	6.5 kVA	7.5 kVA	13.0 kVA
	400 V model		4.0 kVA	5.0 kVA	6.5 kVA	-
Breaker Capacity* <sup>3</sup>	200 V model		15 A	20 A	30 A	40 A
	400 V model		10 A	10 A	15 A	-
Short Circuit Rating (Icu/Ics)			2.5 kA/2.0 kA			7.5 kA/7.5kA
Short-Circuit Current Rating			1.5 kA			
Protective Conductor Current* <sup>4</sup>			0~5 mA			
Ground	200 V model		Type-D* <sup>5</sup>			
	400 V model		Type-C* <sup>4</sup>			-
Noise* <sup>6</sup>			65 dB(A)		70 dB(A)	75 dB(A)

- \*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.
- \*2 200 V model: 3 phase 200 V to 230 V, 400 V model: 3 phase 380 V to 440 V. Separately prepare a power supply for a computer.
- \*3 Prepare an inverter-compatible (medium-speed) breaker.
- \*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.
- \*5 Type-D: 100 Ω or less grounding resistance. Type-C: 100 C or less grounding resistance.
- \*6 Measured 1 m away from the front of the machine.

## 7.1.2 Reinforced Yoke Model

### ■ Table-top type

Model No.		AGX-10kNV2D RY	AGX-20kNV2D RY	AGX-50kNV2D RY
Maximum Capacity		10 kN	20 kN	50 kN
Testing Speed Range		0.0005 to 3000 mm/min	0.0005 to 1500 mm/min	
Testing Speed Precision* <sup>1</sup>		±0.1 %		
Return Speed		0.0005 to 3000 mm/min	0.0005 to 2000 mm/min	
Crosshead Speed and Acceptable Test Force [For all testing speeds]		10 kN	20 kN	50 kN
Frame Stiffness		60 kN/mm or more	180 kN/mm or more	
Stroke Control Resolution		12.5 nm	8.33 nm	
Effective Specimen Width		420 mm	500 mm	
Yoke- Crosshead Distance	Standard	100 to 1100 mm	150 to 1000 mm	
	250 mm Extension	100 to 1325 mm	150 to 1225 mm	
Dimensions Width × Depth × Height	Standard	798×515× 1606 mm	975×579×1763 mm	
	250 mm Extension	798×515× 1856 mm	975×579×2013 mm	
Mass	Standard	100 V	230 kg	-
		200 V	220 kg	480 kg
	250 mm Extension	100 V	240 kg	-
		200 V	230 kg	495 kg
Power Requirements* <sup>2</sup>	100 V model	1.5 kVA	-	
	200 V model	2.0 kVA	5.5 kVA	
Breaker Capacity* <sup>3</sup>	100 V model	15 A	-	
	200 V model	10 A	30 A	
Short Circuit Rating (Icu/Ics)		2.5 kA/1.0 kA		
Short-Circuit Current Rating		1.5 kA		
Protective Conductor Current* <sup>4</sup>		0~5 mA		
Ground		Type-D* <sup>5</sup>		
Noise* <sup>6</sup>		65 dB(A)		

- \*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.
- \*2 200 V model: 3 phase 200 V to 230 V, 400 V model: 3 phase 380 V to 440 V. Separately prepare a power supply for a computer.
- \*3 Prepare an inverter-compatible (medium-speed) breaker.
- \*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.
- \*5 Type-D: 100  $\Omega$  or less grounding resistance. Type-C: 100 C or less grounding resistance.
- \*6 Measured 1 m away from the front of the machine.

## 7.1.3 Wide Model (W1000)

### ■ Table-top type

Model No.		AGX-10kNV2D W1000	
Maximum Capacity		10 kN	
Testing Speed Range		0.0005 to 3000 mm/min	
Testing Speed Precision <sup>*1</sup>		±0.1 %	
Return Speed		0.0005 to 3000 mm/min	
Crosshead Speed and Acceptable Test Force [For all testing speeds]		10 kN	
Frame Stiffness		-	
Stroke Control Resolution		12.5 nm	
Effective Specimen Width		1000 mm	
Crosshead-Table Distance	Standard	180 to 1125 mm	
Dimensions Width × Depth × Height	Standard	1377×504×1582 mm	
Mass	Standard	100 V	350 kg
		200 V	340 kg
Power Requirements <sup>*2</sup>	100 V model		1.5 kVA
	200 V model		2.0 kVA
Breaker Capacity <sup>*3</sup>	100 V model		15 A
	200 V model		10 A
Short Circuit Rating (Icu/Ics)			2.5 kA/1.0 kA
Short-Circuit Current Rating			1.5 kA
Protective Conductor Current <sup>*4</sup>			0~5 mA
Ground			Type-D <sup>*5</sup>
Noise <sup>*6</sup>			65 dB(A)

\*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.

\*2 200 V model: 3 phase 200 V to 230 V, 400 V model: 3 phase 380 V to 440 V. Separately prepare a power supply for a computer.

\*3 Prepare an inverter-compatible (medium-speed) breaker.

\*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.

\*5 Type-D: 100 Ω or less grounding resistance. Type-C: 100 C or less grounding resistance.

\*6 Measured 1 m away from the front of the machine.

## ■ Floor type

Model No.		AGX-50kNV2 W1000	AGX-100kNV2 W1000	AGX-300kNV2 W1000	
Maximum Capacity		50 kN	100 kN	300 kN	
Testing Speed Range		0.0005 to 1500 mm/min		0.0005 to 720 mm/min	
Testing Speed Precision* <sup>1</sup>		±0.1 %			
Return Speed		0.0005 to 2000 mm/min	0.0005 to 1800 mm/min	0.0005 to 720 mm/min	
Crosshead Speed and Acceptable Test Force [For all testing speeds]		50 kN	100 kN	300 kN	
Stroke Control Resolution		8.33 nm		3.33 nm	
Effective Specimen Width		1000 mm			
Crosshead- Table Distance	Standard	255 to 1170 mm	255 to 1170 mm	255 to 1350 mm	
Dimensions Width × Depth × Height	Standard	1606×765× 2170 mm	1606×765× 2170 mm	1606×765× 2420 mm	
Mass	Standard	100 V	1150 kg	1200 kg	1470 kg
		200 V	1200 kg	1210 kg	1490 kg
Power Requirements* <sup>2</sup>	200 V model	4.5 kVA	6.5 kVA	7.5 kVA	
	400 V model	4.0 kVA	5.0 kVA	6.5 kVA	
Breaker Capacity* <sup>3</sup>	200 V model	15 A	20 A	30 A	
	400 V model	10 A	10 A	15 A	
Short Circuit Rating (Icu/Ics)		2.5 kA/2.0 kA			
Short-Circuit Current Rating		1.5 kA			
Protective Conductor Current* <sup>4</sup>		0~5 mA			
Ground	200 V model	Type-D* <sup>5</sup>			
	400 V model	Type-C* <sup>5</sup>			
Noise* <sup>6</sup>		65 dB(A)		70 dB(A)	

\*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.

\*2 200 V model: 3 phase 200 V to 230 V, 400 V model: 3 phase 380 V to 440 V. Separately prepare a power supply for a computer.

\*3 Prepare an inverter-compatible (medium-speed) breaker.

\*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.

\*5 Type-D: 100 Ω or less grounding resistance. Type-C: 100 C or less grounding resistance.

\*6 Measured 1 m away from the front of the machine.

## 7.1.4 Separately Installed Controller Model

### ■ Main unit

Model No.		AGX-20kNV2S	AGX-50kNV2S	AGX-100kNV2S	AGX-300kNV2S	AGX-600kNV2S
Maximum Capacity		20 kN	50 kN	100 kN	300 kN	600 kN
Testing Speed Range		0.00005 to 1500 mm/min			0.00005 to 720 mm/min	0.00005 to 540 mm/min
Testing Speed Precision* <sup>1</sup>		±0.1 %				
Return Speed		0.00005 to 2000 mm/min		0.00005 to 1800 mm/min	0.00005 to 720 mm/min	0.00005 to 540 mm/min
Crosshead Speed and Acceptable Test Force [For all testing speeds]		20 kN	50 kN	100 kN	300 kN	600 kN
Frame Stiffness		180 kN/mm or more	180 kN/mm or more	300 kN/mm or more	400 kN/mm or more	700 kN/mm or more
Stroke Control Resolution		8.33 nm			3.33 nm	2.50 nm
Effective Specimen Width		600 mm				790 mm
Crosshead-Table Distance	Standard	215 to 1265 mm		215 to 1250 mm	215 to 1440 mm	215 to 1650 mm
	250 mm Extension	215 to 1490 mm		215 to 1475 mm	215 to 1665 mm	215 to 1875 mm
	500 mm Extension	215 to 1715 mm		215 to 1700 mm	215 to 1890 mm	215 to 2100 mm
	750 mm Extension	215 to 1940 mm		215 to 1925 mm	215 to 2115 mm	215 to 2325 mm
Dimensions Width × Depth × Height	Standard	1130×765×2170 mm			1130×765×2420 mm	1530×1122×2840 mm
	250 mm Extension	1130×765×2420 mm			1130×765×2670 mm	1530×1122×3090 mm
	500 mm Extension	1130×765×2670 mm			1130×765×2920 mm	1530×1122×3340 mm
	750 mm Extension	1130×765×2920 mm			1130×765×3170 mm	1530×1122×3590 mm

Model No.		AGX-20kNV2S	AGX-50kNV2S	AGX-100kNV2S	AGX-300kNV2S	AGX-600kNV2S
Mass	Standard	200 V	640 kg	810 kg	980 kg	2910 kg
	250 mm Extension	200 V	660 kg	830 kg	1010 kg	2960 kg
	500 mm Extension	200 V	670 kg	850 kg	1030 kg	3020 kg
	750 mm Extension	200 V	690 kg	870 kg	1060 kg	3070 kg
Noise*2			65 dB(A)		70 dB(A)	75 dB(A)

\*1 Test speed precision is calculated from the travel amount within a prescribed time at a constant speed from 0.5 mm/min to 500 mm/min.

\*2 Measured 1 m away from the front of the machine.

### ■ Separate Type AGX-V/R Controller

Model No.		AGX-V/R 50kN	AGX-V/R 100kN	AGX-V/R 300kN	AGX-V/R 600kN
Drive Motor		2.0 kW	3.5 kW	5.5 kW	7.5 kW
Dimensions Width × Depth × Height		320 × 506 × 678 mm			420 × 606 × 678 mm
Mass		30 kg	35 kg	35 kg	55 kg
Power Requirements*1	Voltage*2	3φ 200 to 230 V			
	Frequency	50/60 Hz			
	Capacity	4.5 kVA	6.5 kVA	7.5 kVA	13.0 kVA
Breaker Capacity*3		15 A	20 A	30 A	40 A
Short Circuit Rating (I <sub>CU</sub> /I <sub>CS</sub> )		2.5 kA/2.0 kA			7.5 kA / 7.5 kA
Short Circuit Current Rating		1.5 kA			
Protective Conductor Current*4		0 to 5 mA			
Protective Ground		Type-D grounding*5 with equipotential bonding*6			

\*1 Separately prepare a power supply for the computer.

\*2 The voltage in the table indicates the phase-to-phase voltage.

\*3 Since inrush currents and harmonic currents flow, use a harmonic surge-resistant power breaker.

\*4 The value varies depending on the operation status. The value indicates the current of the fundamental component in a TT grounded system, S-phase grounding.

\*5 The grounding resistance is 100 Ω max.

\*6 When connecting the AGX-V/R controller, optional devices, or computer to separate power sources, make sure that there is no potential difference between all protective earth terminals. (Less than 10 V AC/DC)



## 7.2 Functional Specifications

### ■ Measurement Specifications

Item		Description
Test Force Measurement		
Detection Method		Strain Gauge Load Cell
Measurement Precision*1	High-Precision Unit*2 (1/1000) Capacity: 50 N to 300 kN	Within $\pm 0.5$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1 to 1/1000 load cell ratings) As the Shimadzu shipment standard, it has been verified that the measurement precision is within $\pm 0.3$ % of the indicated value at 1/1 to 1/100 load cell ratings.
	High-Precision Unit*3 (1/500) Capacity: 600 kN	Within $\pm 0.5$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1 to 1/500 load cell ratings) As the Shimadzu shipment standard, it has been verified that the measurement precision is within $\pm 0.3$ % of the indicated value at 1/1 to 1/100 load cell ratings.
	Wide Range -Precision Unit*4 (1/2000) Capacity: 50 N to 300 kN	Within $\pm 1$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1000 to 1/2000 load cell ratings) Within $\pm 0.5$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1 to 1/1000 load cell ratings) As the Shimadzu shipment standard, it has been verified that the measurement precision is within $\pm 0.3$ % of the indicated value at 1/1 to 1/100 load cell ratings.
	Standard -Precision Unit*5 (1/1000) Capacity: 10 N to 300 kN	Within $\pm 1$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1 to 1/1000 load cell ratings)
	Standard -Precision Unit*6 (1/500) Capacity: 600 kN	Within $\pm 1$ % of the displayed test force: Guarantees that the instrument passes the test force validation test. (at 1/1 to 1/500 load cell ratings)

Item		Description
Test Force Display	Display Method	Digital display (on the smart controller)
	Display Unit	Selectable from SI (mN, N, kN), kilogram-force (gf, kgf, tf), or pound-force (lbf, kip)
	Display Item	Current value, peak value (When the special software is enabled) and break point value (When the special software is enabled)
	Display Resolution Capacity: 300 kN, 600 kN	<ul style="list-style-type: none"> <li>• More than 15 % of the load cell rating: 1/30 000</li> <li>• More than 2.2 % to 15 % of the load cell rating: 1/100 000</li> <li>• More than 0.33 % to 2.2 % of the load cell rating: 1/300 000</li> <li>• 0.33 % of the load cell rating or less: 1/1 000 000</li> </ul>
	Display Resolution Capacity: 250 kN	<ul style="list-style-type: none"> <li>• More than 15 % of the load cell rating: 1/10 000</li> <li>• More than 2.2 % to 15 % of the load cell rating: 1/50 000</li> <li>• More than 0.33 % to 2.2 % of the load cell rating: 1/250 000</li> <li>• 0.33 % of the load cell rating or less: 1/1 250 000</li> </ul>
	Display Resolution Capacity: Other than the above	<ul style="list-style-type: none"> <li>• More than 15 % of the load cell rating: 1/10 000</li> <li>• More than 2.2 % to 15 % of the load cell rating: 1/50 000</li> <li>• More than 0.33 % to 2.2 % of the load cell rating: 1/200 000</li> <li>• 0.33 % of the load cell rating or less: 1/1 000 000</li> </ul>
Test Force Measurement Low-pass Filter	Damping Characteristics	Fourth-order Bessel characteristics
	Cutoff Frequency	0.3 Hz, 1 Hz, 3 Hz, 10 Hz, 30 Hz, 100 Hz, 300 Hz, 1000 Hz, 3000 Hz, without filter
	Frequency Switching	Automatic selection according to the measurement condition or user preference
Measurement Range		1 Range (rangeless)
Sampling Frequency		10 kHz max. (configurable with the special software)
Zero Adjustment		Can be executed with dedicated software, smart controller, or operation controller.
Test Force Calibration		Electronic calibration (Can be executed with dedicated software, smart controller, or operation controller.)
Calibration Before Shipment	High-Precision Unit, Wide Range -Precision Unit	Tension, compression, or tension and compression*7
	Standard -Precision Unit	Tension and compression
Crosshead Position Measurement		
Detection Method		Battery-less multiple-turn absolute encoder
Position Detection Precision		Within $\pm 0.05$ % of the indicated value or $\pm 0.01$ mm, whichever is larger

Item		Description
Position Display	Display Method	Digital display (Displayed on the smart controller, operation controller)
	Display Unit	$\mu\text{m}$ , mm, cm, inch, %
	Display Resolution	0.01 $\mu\text{m}$ min. (maximum number of displayed digits: up to seven digits)
Displacement Display (When the Testing machine is equipped with the internal unit)	Display Method	Digital display (Displayed on the smart controller, operation controller)
	Display Unit	$\mu\text{m}$ , mm, cm, inch, %
	Display Resolution	<ul style="list-style-type: none"> <li>• More than 15 % of rating : 1/10 000</li> <li>• 15 % of rating or less: 1/50 000</li> </ul>
Virtual sensor	Function	Performs linear operation on one or more displacement or strain measurements, and registers the results as measurement and control sensors.
	The number of channels	4 Channels
Internal Unit (Optional Product)		
Sensor Amplifier	Number of Channels	1 channel
	Applicable Sensor	Load cell, SG extensometer, SG width gauge, LVDT extensometer, LVDT width gauge
	Excitation Voltage	1.0 Vop, 2.0 Vop, 5.0 Vop, 10 Vop, automatic switching
	Excitation Signal	1 kHz sine wave
	Compatible Connector	Special calibration connector
Analog Input Amplifier	Number of Channels	4 channels
	Input Voltage Range	$\pm 5\text{ V}$ , $\pm 10\text{ V}$
	Absolute Maximum Voltage	$\pm 12\text{ V}$
	Measurement Resolution	24 bits
	Voltage Accuracy	$\pm 0.5\%$ of input voltage or $\pm 10\text{ mV}$ , whichever is larger
	Compatible Connector	BNC connector

Item		Description
Counter Unit	Number of Channels	4 channels
	Pulse Format	90° 2-phase pulse, up/down pulse
	Signal Format	Line driver, 5 V TTL, open collector
	Maximum Pulse Rate	5 MPPS (line driver, 5 V TTL), 100 kPPS (open collector)
	Pulse Count Range	-2 147 483 648 to +2 147 483 647
	Compatible Connector	26-pin half-pitch connector
Strain Amplifier	The number of channels	2 Channels
	Target sensor	Strain gauge bridge
	Excitation voltage	0.5 Vop, 1.0 Vop, 2.0 Vop, 5.0 Vop
	Excitation signal	1 kHz sine wave
	Applicable connector	NDIS connector
	Measurement Accuracy*8	±0.1 % of the full scale
	Measurement range	<ul style="list-style-type: none"> <li>• Excitation voltage of 0.5 Vop ±200000×10<sup>-6</sup> strain</li> <li>• Excitation voltage of 1.0 Vop ±100000×10<sup>-6</sup> strain</li> <li>• Excitation voltage of 2.0 Vop ±50000×10<sup>-6</sup> strain</li> <li>• Excitation voltage of 5.0 Vop ±20000×10<sup>-6</sup> strain</li> </ul>

\*1 The official standards including JIS B7721, EN 10002-2, ISO 7500-1, and ASTM E4 recommend that the Testing machine undergo validation after installation. In a test to measure test force for a long time, such as creep test, drift can occur in the measured values due to changes in ambient temperature or self-heating of the load cell. Set a sufficiently wide range for drift amount when performing such a test.

\*2 The Testing machine of this type conforms to JIS B7721 Grade 0.5, EN 10002-2 Grade 0.5, ISO 7500-1 Class 0.5, BS 1610 Class 0.5, and ASTM E4. For the load cell with a capacity less than 50 N or the load cell with a capacity of 600 kN, the high-precision type (1/1000) settings are not available.

\*3 The Testing machine of this type conforms to JIS B7721 Grade 0.5, EN 10002-2 Grade 0.5, ISO 7500-1 Class 0.5, BS 1610 Class 0.5, and ASTM E4.

\*4 The Testing machine of this type conforms to JIS B7721 Grade 1, EN 10002-2 Grade 1, ISO 7500-1 Class 1, BS 1610 Class 1, and ASTM E4. For the load cell with a capacity less than 50 N or the load cell with a capacity of 600 kN, the wide range-precision type (1/2000) settings are not available.

\*5 The Testing machine of this type conforms to JIS B7721 Grade 1, EN 10002-2 Grade 1, ISO 7500-1 Class 1, BS 1610 Class 1, and ASTM E4. For the load cell with a capacity less than 10 N or the load cell with a capacity of 600 kN, the standard-precision type (1/1000) settings are not available.

\*6 The Testing machine of this type conforms to JIS B7721 Grade 1, EN 10002-2 Grade 1, ISO 7500-1 Class 1, BS 1610 Class 1, and ASTM E4.

\*7 Designate the calibration direction when placing an order.

\*8 Calibration is performed in the factory at excitation voltage of 2.0 Vop and full scale of 50000×10<sup>-6</sup> strain.

## ■ Control Specifications

Item		Description														
Control Frequency		1 kHz														
Stroke Control	Control Resolution	▶▶ Reference "7.1 Basic Specifications" P.104														
	Testing Speed Range															
	Testing Speed Precision															
	Return Speed															
	Acceleration and deceleration rate during test	Initial setting 3000 mm/min/s <table border="1"> <thead> <tr> <th>Model</th> <th>Settable range</th> </tr> </thead> <tbody> <tr> <td>AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10</td> <td>1 to 30000 mm/min/s</td> </tr> <tr> <td>AGX-50kNV2D AGX-50kNV2D RY</td> <td>1 to 15000 mm/min/s</td> </tr> <tr> <td>AGX-50kNV2 AGX-50kNV2 W10 AGX-50kNV2S</td> <td>1 to 15000 mm/min/s</td> </tr> <tr> <td>AGX-100kNV2 AGX-100kNV2 W10 AGX-100kNV2S</td> <td>1 to 15000 mm/min/s</td> </tr> <tr> <td>AGX-300kNV2 AGX-300kNV2 W10 AGX-300kNV2S</td> <td>1 to 7200 mm/min/s</td> </tr> <tr> <td>AGX-600kNV2 AGX-600kNV2S</td> <td>1 to 5400 mm/min/s</td> </tr> </tbody> </table>	Model	Settable range	AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10	1 to 30000 mm/min/s	AGX-50kNV2D AGX-50kNV2D RY	1 to 15000 mm/min/s	AGX-50kNV2 AGX-50kNV2 W10 AGX-50kNV2S	1 to 15000 mm/min/s	AGX-100kNV2 AGX-100kNV2 W10 AGX-100kNV2S	1 to 15000 mm/min/s	AGX-300kNV2 AGX-300kNV2 W10 AGX-300kNV2S	1 to 7200 mm/min/s	AGX-600kNV2 AGX-600kNV2S	1 to 5400 mm/min/s
	Model	Settable range														
	AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10	1 to 30000 mm/min/s														
	AGX-50kNV2D AGX-50kNV2D RY	1 to 15000 mm/min/s														
	AGX-50kNV2 AGX-50kNV2 W10 AGX-50kNV2S	1 to 15000 mm/min/s														
	AGX-100kNV2 AGX-100kNV2 W10 AGX-100kNV2S	1 to 15000 mm/min/s														
AGX-300kNV2 AGX-300kNV2 W10 AGX-300kNV2S	1 to 7200 mm/min/s															
AGX-600kNV2 AGX-600kNV2S	1 to 5400 mm/min/s															
Distance between Jigs Setting	The crosshead can be moved to an appropriate start position according to a registered distance between jigs. Minimum distance between jigs <ul style="list-style-type: none"> <li>• In the tensile test mode: 20 mm</li> <li>• In the compression/three-point/four-point bending test mode: 0 mm</li> </ul>															
Distance between Jigs Speed	Same as the return speed															
Test Force Control	Control Parameter	Automatic setting through auto-tuning														
Stress Control																
Elongation Control*1																
Strain Control*1																

\*1 An extensometer is separately needed for elongation and strain control.

## ■ Input and Output Specifications

Item	Description	
Standard Equipment		
Analog Output	Number of Channels	2 channels
	Full Scale (FS)	5 V or 10 V (Switched depending on the setting)
	Output Voltage Range	$\pm 5$ V (FS: 5 V), $\pm 10$ V (FS: 10 V)
	Output Resolution	168 $\mu$ V (FS: 5 V), 336 $\mu$ V (FS: 10 V)
	Output Rate	100 kHz
	Voltage Accuracy	$\pm 0.5$ % of input voltage or $\pm 10$ mV, whichever is larger
	Output Content	Test force, stroke, and values measured with the internal unit (optional)
	Output Adjustment	0 V, FS Forced output is possible
	Compatible Connector	BNC connector
Non-Isolated PIO Unit	Number of Channels	1 channel
	Input Bit Count	16 bits
	Output Bit Count	16 bits
	Input Signal Format	5 V TTL, open collector
	Output Bit Count	Open collector
	Compatible Connector	D-sub 37-pin male connector

Item		Description
Internal Unit (Optional)		
Analog Output Amplifier	Number of Channels	4 channels
	Full Scale (FS)	5 V or 10 V (Switched depending on the setting)
	Output Voltage Range	$\pm 5$ V (FS: 5 V), $\pm 10$ V (FS: 10 V)
	Output Resolution	168 $\mu$ V (FS: 5 V), 336 $\mu$ V (FS: 10 V)
	Output Rate	100 kHz
	Voltage Accuracy	$\pm 0.5$ % of input voltage or $\pm 10$ mV, whichever is larger
	Output Content	Test force, stroke, and values measured with the internal unit (optional)
	Output Adjustment	0 V, FS Forced output is possible
	Compatible Connector	BNC connector
Non-Isolated PIO Unit	Number of Channels	1 channel
	Input Bit Count	16 bits
	Output Bit Count	16 bits
	Input Signal Format	5 V TTL, open collector
	Output Bit Count	Open collector
	Compatible Connector	D-sub 37-pin male connector
Insulation PIO Unit	Number of Channels	1 channel
	Input Bit Count	16 bits
	Output Bit Count	16 bits
	Input Signal Format	12 to 24 V AC/DC photocoupler insulation
	Output Bit Count	12 to 24 V AC/DC photo MOS relay insulation
	Compatible Connector	D-sub 37-pin female connector
Analog Recorder Unit	Applicable Analog Recorder	AR series
	Compatible Connector	D-sub 9-pin male connector

## ■ Controller Specifications

Controller		Operation Controller	Smart Controller
Measured Value Display Mode		5 display modes are provided: <ul style="list-style-type: none"> <li>• 3 measured values + graphs + test conditions</li> <li>• 5 measured values + graphs</li> <li>• 10 measured values</li> <li>• 3 measured values (with large characters)</li> <li>• Graphs (large)</li> </ul>	2 display modes are provided: <ul style="list-style-type: none"> <li>• 2 measured values + test conditions</li> <li>• 4 measured values</li> </ul>
Crosshead Movement	Hard Button Operation	Test Start / Return / Test Stop / Manual ON/OFF / Jog up / Jog down / Emergency stop	Manual ON/OFF, Jog up, Jog down
	Jog Dial Operation	Fine adjustment of crosshead position	
	Touch Panel Operation	Test Start / Test Stop / Return / Specimen Protection / distance movement between jigs	Test piece Protection / distance movement between jig



Controller		Operation Controller	Smart Controller
Method Setting	Control Parameter	Stroke / test force / stress / displacement / strain / virtual sensor* <sup>1</sup>	
	Control Mode* <sup>2</sup>	One-direction (single) test mode Performs a test by driving the crosshead in one direction with the control parameter. <ul style="list-style-type: none"> <li>Control hold position: 1 point can be registered within control parameter.</li> <li>Control hold time: 1 to 99999 seconds</li> </ul>	
		Cycle test mode Performs a test by repeatedly driving the crosshead vertically with the control parameter. <ul style="list-style-type: none"> <li>Reverse set position: 2 points at the maximum point (control parameter) and the minimum point (control parameter)</li> <li>Hold control at reverse position: Possible Control hold time: 1 to 99999 seconds</li> <li>Maximum cycle number: 1000 cycles</li> <li>Cycle count function: Supplied</li> <li>Motion after set cycle number is reached: Stop or break Stop: Loading is automatically stopped. Break: Load is kept applied until a break is detected exceeding the maximum point of the reverse set position.</li> </ul>	
		Stress auto mode Registers 1 stress speed, 1 strain speed, 1 stroke speed, and 2 switch points (1st: auto switch, 2nd: stroke setting).	
		Strain test mode Registers 1 strain speed, 2 stroke speeds, and 2 switch points (1st: strain, 2nd: stroke setting).	
		3-step stroke test control mode Registers 3 stroke speeds, and 2 switch points (stroke).	
Specimen Information Settings* <sup>3</sup>	<ul style="list-style-type: none"> <li>Tensile tests: Plate / Rod / Area</li> <li>Compression tests: Prismatic column / Cylinder / Area</li> <li>3-point bend / 4-point bend tests: Prismatic column / Cylinder</li> </ul>		

Controller		Operation Controller	Smart Controller
Graph Display	Parameter	Stroke / test force / stress / displacement / strain / virtual sensor / time <sup>*4</sup>	-
	Function	Draws time graphs and X-Y graphs during a test. <sup>*5</sup>	-
USB Drive Connection		Connecting a USB drive to the AGX-V/R Control/Measuring unit allows for using the following function: <ul style="list-style-type: none"> <li>• Screen capture Captures the main screen and saves it as an image file.<sup>*6</sup></li> <li>• Real-time data sampling Allows for saving the real-time data of total 3 channels: stroke, test force (or stress), and installed sensor 1 channel.<sup>*7 *8</sup></li> </ul>	-
Method File		Saves and load method settings (25 types).	-

\*1 The items may vary depending on the installed sensor.

\*2 The Testing machine has use restrictions for the continuous operation and cycle test. (See "Use Restrictions" P.126)

\*3 This setting is used for stress and strain value display.

\*4 The items may vary depending on the installed sensor.

\*5 Can be drawn up to 30 minutes from test start.

\*6 Portable Network Graphics (PNG) format

\*7 Can sample data up to 30 minutes from test start.

\*8 Data is saved in the CSV format.

## ■ Voice operation device specifications

Item	Description	
Testing machine Operation <sup>*1</sup>	Shutdown	Testing machine power off, standby off
	Crosshead Operation <sup>*2</sup>	Test start, return start, inter-jig distance travels, specimen protection start, jig operations, stop
	Test/measured values	E-CAL execution, zero reset, peak value/ break point value response, test starting direction response
	Others	Wake-up word registration, chuck open, SIE operation, screen change
Voice operation device body size (Outer Diameter x Thickness)	60×20 mm	
Weight	303 g	
Cable Length	1.5 m (Standard model, Reinforced yoke model, Wide model) 3.0 m (Separately installed controller model)	

\*1 Voice operation is possible only when the operation assistance with voice guidance of the main unit is ON ("Other Functional Specifications" P.125).

\*2 Crosshead operation is possible only when the protection cover function is ON.

## ■ Communication Specifications

Item		Description
Computer Communication	LAN communication*1	100BASE-TX
	LAN Cable	UTP category 6
	Maximum Cable Length*2	100 m
	Compatible Connector	RJ-45 connector

\*1 Do not use a hub (wired/wireless) but connect a PC and the instrument directly with a LAN cable.

\*2 The maximum length of a LAN cable is 100 m. Use a cable as short as possible.

## ■ Safety and Protection Functions

Item		Description
Safety Function	Emergency Stop Switch	Two located on the front side*1*2
	Stroke Limit Switch	Crosshead upper and lower limits can be set (photoelectric sensor)
	Software Limits	Upper and lower limits of displacement or test force can be set
	Overload Limit	<ul style="list-style-type: none"> <li>An alarm is issued and the instrument stops when the measured value after zero offset is equal to or more than <math>\pm 102\%</math> of the load cell rating.</li> <li>An alarm is issued and the instrument stops when the measured value before zero offset is equal to or more than <math>\pm 150\%</math> of the load cell rating.</li> </ul> <p>▶▶ Reference "3.6.2 Overload/Underload Detection Function" P.64</p>
	"TouchLoad" Detection	<p>An alarm is issued and the instrument stops when test force fluctuates during the jog operation, return, and movement to the distance between jigs.</p> <p>▶▶ Reference "3.6.1 Contact Detect Function" P.62</p>
	Servo Motor Overload Protection	An alarm is issued and the instrument stops when the specified value is reached.
	Servo Amplifier Overload Protection	An alarm is issued and the instrument stops when the specified value is reached.
	Earth Leakage Breaker	Supplied
	Ball Screw Protection Cover	Supplied
Jig Collision Prevention Function	Distance between jigs can be registered to prevent collision between jigs (this function requires special software).	

## 7 References

Item		Description
Maintenance Function	Self-Maintenance Function	10-year inspection notification function
	Self-Check Function	Monitors the powering time, motor on time, servo on time, travel distance of the crosshead, emergency stop switch operation count, stroke limit activation count, backlight lighting time, button operation count, jog dial count, touch panel operation count, power supply voltage, and cooling fan speed.
	Log Save Function	Supplied (this function requires special software)
Alarm Sound		An alarm sound is emitted.
Protection Cover	Front Side	Door type (The upper portion is fixed)
	Rear Side	Fixed
	Material	Polycarbonate (thickness: 3 mm)
	Interlock	Supplied Only the jog operation and jog dial operation can be used at a crosshead speed of 50 mm/min or less when the door is open.

\*1 One additional column-mount type switch is included in the reinforced yoke model.

\*2 Wide model with protection cover comes with one additional table-top type switch.

## ■ Other Functional Specifications

Item		Description
Specimen Break Detection Function	Setting	Can be set with the special software and the smart controller, as part of the test conditions
	Types of Detection Functions	Voluntary settings of break sensitivity, break level, and peak break level (can be enabled and disabled individually)
	Start Point of Break Detection	The break detection starts when the test force increases equal to or more than "test force S". Any value within $\text{Break Level} < S \leq 99.999 \%$ /load cell rating
	Break Sensitivity	After the start point of break detection, when the test force decreases with a gradient equal to or more than "test force A" per second, it is detected as a break. Any value within $0.005/\text{load cell rating} \leq A \leq 1000 \%$ /load cell rating can be set.
	Break Level	After the start point of break detection, when the test force decreases to "test force B", it is detected as a break. Any value within $0.001 \leq B \leq \text{Start Point of Break Detection}$ can be set.
	Peak Break Level	After the start point of break detection, when the test force decreases to "C %/peak test force," it is detected as a break. Any value within $0.1 \leq C \leq 99.99 \%$ can be set.
	Crosshead Movement When Specimen Is Broken	Stop, or origin return (Select either of them)
Sound Function	Select operation sound according to the surrounding environment (Standard/Clear/Silent) Operation assistance with voice guidance (ON/OFF) Volume setting (5 levels)	
Power Save Function	Turning off the servo power, turning off the backlight for the LCD operating panel  ▶▶ Reference "Precision Universal Testing Machines AUTOGRAPH AGX-V2 Series Reference Manual" (Document No.: 349-11986)	

## 7.3 Use Restrictions and Installation Environment

### ■ Use Restrictions

Item	Description														
Continuous Operating Time	Max. 10 hours														
Cycle Test	<ul style="list-style-type: none"> <li>Set power*1: The test speed × set test force must not exceed the following values.</li> </ul> <table border="1"> <thead> <tr> <th>Model</th> <th>Set power</th> </tr> </thead> <tbody> <tr> <td>AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10</td> <td>15000 kN · mm/min</td> </tr> <tr> <td>AGX-50kNV2D AGX-50kNV2D RY</td> <td>37500 kN · mm/min</td> </tr> <tr> <td>AGX-50kNV2 AGX-50kNV2S AGX-50kNV2S W10</td> <td>37500 kN · mm/min</td> </tr> <tr> <td>AGX-100kNV2 AGX-100kNV2S AGX-100kNV2 W10</td> <td>75000 kN · mm/min</td> </tr> <tr> <td>AGX-300kNV2 AGX-300kNV2S AGX-300kNV2 W10</td> <td>108000 kN · mm/min</td> </tr> <tr> <td>AGX-600kNV2 AGX-600kNV2S</td> <td>162000 kN · mm/min</td> </tr> </tbody> </table>	Model	Set power	AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10	15000 kN · mm/min	AGX-50kNV2D AGX-50kNV2D RY	37500 kN · mm/min	AGX-50kNV2 AGX-50kNV2S AGX-50kNV2S W10	37500 kN · mm/min	AGX-100kNV2 AGX-100kNV2S AGX-100kNV2 W10	75000 kN · mm/min	AGX-300kNV2 AGX-300kNV2S AGX-300kNV2 W10	108000 kN · mm/min	AGX-600kNV2 AGX-600kNV2S	162000 kN · mm/min
	Model	Set power													
	AGX-10kNV2D AGX-10kNV2D RY AGX-10kNV2D W10	15000 kN · mm/min													
	AGX-50kNV2D AGX-50kNV2D RY	37500 kN · mm/min													
	AGX-50kNV2 AGX-50kNV2S AGX-50kNV2S W10	37500 kN · mm/min													
	AGX-100kNV2 AGX-100kNV2S AGX-100kNV2 W10	75000 kN · mm/min													
	AGX-300kNV2 AGX-300kNV2S AGX-300kNV2 W10	108000 kN · mm/min													
	AGX-600kNV2 AGX-600kNV2S	162000 kN · mm/min													
	<ul style="list-style-type: none"> <li>Continuous Cycle Count: Max. 1000 cycles</li> </ul>														
Attaching T Slot (Pole) Jig	<ul style="list-style-type: none"> <li>T nut to be used: Easy nut made by SUS</li> <li>Maximum weight of jig: 3 kg max. per jig, gross weight of 5 kg max.</li> <li>Jig size: The jig must not enter the test space.</li> </ul>														

\*1 Cycle test can be performed in the range that the product of set test speed and maximum target test force does not exceed these values.

## ■ Installation Environment

Item		Description
Temperature* <sup>1</sup>		+5 °C to +40 °C
Humidity* <sup>2</sup>		20 % to 80 %
Power Supply Voltage Fluctuation		Max. ±10 % of the nominal value
Vibration	Frequency	Max. 10 Hz
	Amplitude	Max. 5 μm
	Vibration Acceleration Level	Max. 65.9 dB (The above frequency and amplitude are converted based on the reference value $1 \times 10^{-5} \text{ m/s}^2$ )
Noise		55 dB ( A ) or less when voice operation is used* <sup>3</sup>

\*1 With max. ±2 °C variation during a test

\*2 Without condensation

\*3 Loud environmental noises may disturb voice operation.

# Index

## Numerics

10 kN (Table-Top) Type	13
20/50 kN (Table-Top) Type	15
20/50/100/300 kN (Floor) Type	17
600 kN (Floor) Type	19

## A

AEH Communication Unit	11
AGX-V/R controller	9, 25, 112
Alarm Code	87
Analog Input Amplifier	11
Analog out	31
Analog Output Amplifier	11
Analog Output Connector	22, 26
Analog Recorder Unit	11

## B

Ball Screw	14, 16, 18, 20, 24, 76
Ball Screw Protection Cover	14, 16, 18, 20, 24
Bar Indicator	22, 25

## C

Cable clamp	8, 10
CAL Connector	11, 35
Calibration	31, 42
Checking the Stroke Speed	75
Checking the Test Force	73
Consumables	103
Contact Detect Function	62
Control Box	14, 16, 18, 20, 21
Controller	120
Cooling Fan	14, 16, 18, 20, 24, 25
Cooling Fan Filter	78, 103
Counter Unit	11
Crosshead	14, 16, 18, 20, 24
Crosshead Lower Limit	14, 16, 18, 20, 24
Crosshead Origin Return	46
Crosshead Upper Limit	14, 16, 18, 20, 24
Crossyoke	14, 16, 18, 20, 24

## D

Distance Between Jigs	50
-----------------------	----

## E

E-CAL	42
Emergency Stop Switch	8, 12, 14, 16, 18, 20, 24, 31, 61, 71
Ending a Test	68
Error Indicator	22, 25
Ethernet Connector	22, 26
Extension Slot	22, 26

## F

Fall prevention anchor	12
File	31
Filter	25
Fixing plate	32
Floor Type	3, 105, 110
Front Cover	24

## G

Grease	103
Guide Poles	77

## H

Hex wrench set	8, 10
----------------	-------

## I

Installation Environment	127
Inter-jig distance	29, 31
Interlock Connector	22, 26
Isolated PIO Unit	11

## J

Jog Dial	29, 31
Jog Dial Max. Speed	48
Jog Down Button	29, 31
Jog Speed	48
Jog Up Button	29, 31

## L

LED indicator	32
Limit Switch	57, 71
Load Cell	14, 16, 18, 20, 24, 35

## M

Magnet	32
Maintenance	31
Maintenance Parts	103
Manual Button	29, 31
Method	31
Microphones	32

## N

Non-Isolated PIO Unit	11
-----------------------	----

## O

Operating Panel	101
Operating Panel Connector	22, 26
Operation Controller	6, 9, 14, 16, 18, 20, 24, 79, 120
Operation Unit	79
Overload	64



<b>P</b>	
PIO Connector	22, 26
Pole	14, 16, 18, 20, 24
Power Button	22, 25, 40
Power Control Connection Port	24
Power Supply	100
Power Supply Breaker	14, 16, 18, 20, 25
Power supply cable	6, 9, 16, 18, 20
Power Supply Connector	14
Protection Cover	14, 16, 18, 20, 24, 60, 72
Protective glasses	8, 10, 103
Protective gloves	8, 10, 103

<b>R</b>	
Reinforced Yoke Model	13, 107
Return Button	31
Return Home	29
Return Speed	48
Rotation bar	7, 10

<b>S</b>	
Sensor Amplifier	11, 22, 26
Separately Installed Controller Model	23, 111
Servo Motor	100
Set	29
Settings	31
Shortcut connector	8, 10
Smart controller	6, 9, 14, 16, 18, 20, 24, 79, 120
Software Limits	61
Specimen protection	29, 31
Stand	32
Standard Model	13, 104
Standby Button	22, 25, 41, 64
Start Button	31
Start Test	29
Starting a Test	66
Stop Button	31
Stop Test	29
Strain Amplifier	11
Synchronization Connector	22, 26
System Reset	102

<b>T</b>	
Table	14, 16, 18, 20, 24
Table-top Type	2, 104, 107, 109
TD1	22
TD2 to TD6	22
Touch Panel	29, 31
Turning On/Off the Power	39

<b>U</b>	
Underload	64
Usage Time/Counts	80
USB Cable	32

USB Connector	22, 26
USB connector cap	8, 10
USB extension cable	10
Use Restrictions	126

<b>V</b>	
Voice control device	6, 9, 14, 16, 18, 20, 24, 79
Voice operation device	122

<b>W</b>	
warming up	42
Wide Model	13, 109

<b>Z</b>	
Zero Reset	29, 31

This page is intentionally left blank.